SAMSUNG



ENGLISH

SAMSUNG CAMERA

User's Manual

Digimax A402

Thank you for buying a Samsung Camera.
This manual will guide you through using the camera, including capturing images, downloading images and using the software applications. Please read this manual carefully before using your new camera.

Downloaded From camera-usermanual.com Samsung Manuals

Instructions

■ Use this camera in the following order


Set up the camera driver
Before connecting the camera to a PC, via the USB cable, you will need to set up the camera driver. Install the camera driver that is contained in the Application S/W CD-ROM.(p.89)
Take a picture
Take a picture (p.19)
Insert the USB cable
Insert the supplied USB cable into the PC's USB port and the camera's USB connection terminal.(p.95)
Check the camera's power
Check the camera's power. If the power is turned off, press the camera button to turn on.
Check [Removable Disk]
Open Window' s EXPLORER and search for [Removable Disk].(p.96)

● If you use a card reader to copy the images on the memory card to your PC, the images could be damaged. When transferring the images taken with the camera to your PC, be sure to use the supplied USB cable to connect the camera to your PC. Please note that the manufacturer holds no responsibility for loss or damage of images on the memory card due to the use of a card reader.

Downloaded From camera-usermanual.com Samsung Manuals

Contents

READY

- Getting to know your camera ····· 5
- About the icons ····· 5
- Danger ····· 6
- Warning ····· 6
- Caution ····· 7
- An FCC warning ····· 7
- System chart ····· 8
- Identification of features ····· 10
  - Front & Top ····· 10
  - Back & Bottom ····· 10
  - Side / 5-function button ····· 11
  - Mode button ····· 11
- Instructions on how to use the power source ····· 13
  - Using the batteries ····· 13
- Connecting to a Power Source ····· 14
  - Using the batteries ····· 14
- Instructions on how to use the memory card ····· 15
  - Maintenance of the memory card ····· 15
  - Preserving the memory card data ····· 15
- Inserting the memory card ····· 17
- Removing the memory card ····· 17

RECORDING

- LCD monitor indicator ····· 18
- Starting the recording mode ····· 19
  - Taking a still image ····· 19
  - Recording a Movie clip ····· 20
  - Using Successive Recording ····· 20
  - How to use the VOICE RECORDING mode ····· 21
  - Pausing while recording a voice recording ····· 21
- Things to watch out for when taking pictures ····· 22
- Using the camera buttons to adjust the camera ····· 23
  - POWER button ····· 23
  - SHUTTER button ····· 23
- ZOOM W/T button ····· 24
- Voice memo/ UP button ····· 25
- Down button ····· 25
- Flash/ Left button ····· 26
- Self-timer/ Right button ····· 28
- MENU/ OK button ····· 29
- +/- button ····· 30
- LCD button ····· 33
- Using the LCD monitor to adjust the camera settings ····· 34
- How to use the menu ····· 36
  - Mode ····· 36
  - Size ····· 37
  - Quality ····· 38
  - Metering ····· 39
  - Continuous shot ····· 40
  - Effect ····· 40
  - Photo Frame ····· 41
  - Sharpness ····· 42
  - Save / Load the camera configuration (MYSET) ····· 43

PLAY

- LCD monitor indicator ····· 44
- Starting play mode ····· 45
  - Playing back a still image ····· 45
  - Playing back a movie clip ····· 46
  - Playing back a recorded voice ····· 46
- Using the camera buttons to adjust the camera ····· 47

Downloaded From camera-usermanual.com Samsung Manuals

Contents

- Thumbnail/ Enlargement button ····47
- Voice memo / Up button ····48
- Play & Pause/ Down button ····49
- LEFT/ RIGHT/ MENU/ OK button ····50
- LCD button ····50
- Delete button ····51
- Setting up the play back function using the LCD monitor ····52
- Starting the slide show ····55
- Rotating an image ····56
- Resize ····57
- Protecting images ····58
- Deleting all images ····59
- DPOF ····59
- DPOF : STANDARD ····60
- DPOF : INDEX ····60
- DPOF : PRINT SIZE ····61
- DPOF : CANCEL ····61
- COPY TO CARD ····62
- PictBridge ····63
- PictBridge: Picture Selection ····64
- PictBridge: Printing ····65
- PictBridge: Print Setting ····66
- PictBridge : RESET ····67

SETUP

- Setup menu ····68
- File name ····69
- Auto power off ····70
- Language ····71
- Formatting a memory card ····72
- Setting up the Date ····73
- Setting up the Time ····73
- Date type ····74
- Imprinting the recording date ····74
- Beep ····75
- Selecting an External Device (USB) ····75
- Quick view ····76
- Initialization(RESET ALL) ····76
- Setting up the MYCAM menu ····77
  - ■ Start up image ····77
  - ■ Start up sound ····78
- Important notes ····79
- Warning indicator ····81
- Before contacting a service centre ····82
- Specifications ····85

SOFTWARE

- Software Notes ····87
- System Requirements ····87
- About the software ····88
- Setting up the application software ····89
- Starting PC mode ····95
- Removing the USB Driver for Windows 98SE ····98
- Removable Disk ····99
- Removing the removable disk ····100
- Setting up the USB Driver for MAC ····101
- Using the USB Driver for MAC ····101
- Digimax Viewer 2.1 ····102
- Using PhotoImpression ····103
- FAQ ····104

Downloaded From camera-usermanual.com Samsung Manuals

Getting to know your camera

Thank you for buying a Samsung Digital Camera.

- Prior to using this camera, please read the user manual thoroughly.
- When you require After Sales service, please bring the camera and the cause of the camera malfunction (such as Batteries, Memory card etc.) to the A/S centre.
- Please check that the camera is operating properly prior to when you intend to use it (e.g. for a trip or an important event) to avoid disappointment. Samsung camera takes no responsibility for any loss or damages that may result from camera malfunction.
- Keep the manual in a safe place.

* Microsoft, Windows and Windows logo are registered trademarks of Microsoft Corporation incorporated in the United States and/or other countries.
* All brand and product names appearing in this manual are registered trademarks of their respective companies.

About the icons

This manual contains instructions on using this camera that will help you to use this camera safely and correctly. This will help prevent danger and injury to others.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, may result in a minor or moderate injury.

Downloaded From camera-usermanual.com Samsung Manuals

Danger

- Do not attempt to modify this camera in any way. This may result in fire, injury, electric shock or severe damage to you or your camera. Internal inspection, maintenance and repairs should be carried out by your dealer or Samsung Camera Service centre.
- Please do not use this product in close proximity to flammable or explosive gases, as this could increase the risk of explosion.
- Should any form of liquid or a foreign object enter the camera, do not use it. Switch off the camera, and then disconnect the power source.
  You must contact your dealer or Samsung Camera Service centre.
  Do not continue to use the camera as this may cause a fire or electric shock.
- Do not insert or drop metallic or inflammable foreign objects into the camera through access points e.g. the memory card slot and battery chamber.
  This may cause a fire or electric shock.
- Do not operate this camera with wet hands. This could pose a risk of electric shock.

DANGER

Warning

- Do not use the flash in close proximity to people or animals.
  Positioning the flash too close to your subject's eyes, may cause eyesight damage.
- When taking photographs, never point the lens of the camera directly into very strong light. This may result in permanent damage to your eyesight.
- For safety reasons keep this product and accessories out of reach of children or animals to prevent accidents e.g.:
  - Swallowing batteries or small camera accessories. If an accident should occur, please consult a doctor immediately.
  - There is the possibility of injury from the camera's moving parts.
- Batteries and camera may become hot during prolonged use and it may result in camera malfunction. Should this be the case, allow the camera to sit idle for a few minutes to allow it time to cool.
- Do not recharge non rechargeable batteries. This may cause an explosion.
- Do not leave this camera in places subject to extremely high temperatures, such as a sealed vehicle, direct sunlight or other places of extreme variances in temperature.
  Exposure to extreme temperatures may adversely affect the camera' s internal components and could cause a fire.
- When in use, do not cover the camera.
  This may cause heat to build up and distort the camera body or cause a fire.
  Always use the camera and its accessories in a well-ventilated area.

WARNING

Downloaded From camera-usermanual.com Samsung Manuals

Caution

- Leaking, overheating, or burst batteries could result in fire or injury.
  - Use batteries with the correct specification for the camera.
  - Do not short circuit, heat or dispose of batteries in fire.
  - Do not insert the batteries with the reverse polarities.
- Remove the batteries when not planning to use the camera for a long period of time. Batteries may leak corrosive electrolyte and permanently damage the camera's components.
- Do not fire the flash while it is in contact with hands or objects.
  Do not touch the flash after using it continuously. It may cause burns.
- A non-rechargeable (disposable) battery can be used but has a short lifespan because of its relatively low battery capacity. We recommend the rechargeable battery which has a bigger capacity and longer lifespan than the non rechargeable type. (Rechargeable batteries may not be available everywhere).



An FCC warning

- This device has been tested in accordance with the limits of a class B digital device under item 15 of the FCC rules. These limits are designed to provide protection against harmful interference in commercial installation. This equipment generates, absorbs and can emit radio frequency energy. If it is not installed and used in accordance with the instructions, it may cause harmful interference to radio communication.
  There is however, no guarantee that interference will not occur in some situations. Should any interference occur when this device is in operation, please try one or more of the following measures.

  - Change the location and direction of any aerial.
  - Increase distance between the camera and the affected device.
  - Use a different socket away from the affected device.
  - Please contact a Samsung agent or a radio/TV engineer.

- This device complies with part 15 of the FCC Rules.
- Changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Downloaded From camera-usermanual.com Samsung Manuals

System chart

Please check that you have the correct contents before using this product. To buy the optional equipment, contact your nearest Samsung dealer or Samsung service centre.

< Included items >

Pouch

User manual
Product warranty

Camera strap

Software CD
(see p.88)



DPOF compatible
printer(see p.59)

SD memory card
(see p.15)

CR-V3 battery

Rechargeable batteries
(SNB-2312)

Rechargeable battery
(SBP-1303)

AA Alkaline
Batteries

AC cord

Battery charger
(SBC-N1)

Battery charger
(SBC-L1)

Downloaded From camera-usermanual.com Samsung Manuals

System chart

Computer
(see p.95)



PictBridge compatible
printer(see p.63)

USB cable

System Requirements

For Windows

- PC with processor better than MMX Pentium 233MHz (XP : Pentium II 300MHz)
- Windows 98/ 98SE/ 2000/ ME/ XP
- Minimum 32MB RAM (XP : 128MB)
- 140MB of available hard-disk space
- USB port
- CD-ROM drive
- 800x600 pixels, 16-bit colour display compatible monitor (24-bit colour display recommended)

For Macintosh

- Power Mac G3 or later
- Mac OS 9.2~10.3
- Minimum 64MB RAM
- 110MB of available hard-disk space
- USB port
- CD-ROM drive
- QuickTime 6.01 or later for Movie Clip

CAUTION

When you connect the camera to a computer or printer, you have to use the USB cable supplied with the camera, or the external devices may not recognise the camera.

Downloaded From camera-usermanual.com Samsung Manuals

Identification of features

Front & Top



Back & Bottom



Downloaded From camera-usermanual.com Samsung Manuals

Identification of features

Side / 5-function button





※ The OK button written in this manual means the MENU button.

Mode button

- You can select the desired working mode by using the mode button located on the back of the camera. This digital camera has 2 recording modes. These are listed below.
- Pressing the mode button will change the camera modes in order. (Still image mode → Movie clip mode)
- Whenever the camera is turned on, the still image mode will display.

● Still image mode

You can select from AUTO( ), PROGRAM( ) or SCENE mode. In SCENE mode, you can select the NIGHT, PORTRAIT, LANDSCAPE and FIREWORKS scene menu.

● Movie clip mode

A movie clip can be recorded for as long as the available recording time of the memory capacity allows. Image size and type are listed below.
- Image size : 640X480, 320X240 (user selectable)
- Movie clip file type : *. AVI(MJPEG)

Downloaded From camera-usermanual.com Samsung Manuals

Identification of features

■ Self-timer lamp

Icon	Status	Description
	Blinking	For the 2 seconds, the lamp blinks quickly at 0.25-second intervals.
	Blinking	For the first 7 seconds, the lamp blinks at 1 second intervals. For the final 3 seconds, the lamp blinks quickly at 0.25-second intervals.
	Blinking	A picture will be taken after about 10 seconds and 2 seconds later a second picture will be taken.

■ Camera Status Lamp

Status	Description
Power on	The lamp turns on and off when the camera is ready to take a picture
After taking a picture	The lamp blinks while saving the image data and turns off when the camera is ready to take a picture
While movie recording	The lamp blinks at a 1-second interval
While voice recording	The lamp blinks at a 1-second interval
When the USB cable is inserted	The lamp lights up (LCD monitor turns off)
Transmitting Data	The lamp blinks (LCD monitor turns off)

■ Mode icons

MODE	AUTO	PROGRAM	MOVIE CLIP	VOICE RECORDING	PLAY
Icon					

MODE	SCENE			
	NIGHT	PORTRAIT	LANDSCAPE	FIREWORKS
Icon				

Downloaded From camera-usermanual.com Samsung Manuals

Instructions on how to use the power source

■ You can use batteries only to provide the camera with power.

Using the batteries

- We recommend using batteries for a digital camera (Within a year from the date of manufacture). The batteries are listed below.

Non rechargeable batteries	:	AA type	- Alkaline
		CR-V3 type	- Lithium Ion battery
Rechargeable batteries	:	AA type	- Ni-MH battery (Samsung SNB-2312 recommended)
		CR-V3 type	- Lithium Ion battery (Samsung SBP-1303 recommended)

- It is easy to buy alkaline batteries. However, the duration for using batteries varies in accordance with the battery manufacturer or the photographic conditions.
- When the camera is not used, turn off the camera power.
- Do not recharge the non rechargeable batteries. It may cause an explosion.
- Please remove the batteries if the camera will not be used for long periods. Batteries can lose power over time and are prone to leaking if kept inside the camera.
- We recommend high capacity batteries (listed above) as manganese batteries cannot deliver sufficient power.
- Low temperatures (below 0°C) can affect the performance of the batteries and you may experience reduced battery life. Batteries will usually recover at normal temperatures.
- Do not use old and new batteries at the same time.
- During extended use of the camera, the camera body may become warm. This is perfectly normal.

Downloaded From camera-usermanual.com Samsung Manuals

Connecting to a Power Source

Using the batteries

: If the camera does not turn on after you have inserted batteries, please check whether the batteries are inserted with the correct polarity (+ / -).



1. Open the battery chamber cover by pushing in the direction of the arrow.



[Inserting the AA type battery]



[Inserting the CR-V3 type battery]

2. Insert the batteries taking note of the polarity (+ / -).



3. To close the battery chamber cover, push it until it clicks.

■ There are 3 indicators for battery condition that are displayed on the LCD monitor.

Battery indicator			
Battery status	The batteries are fully charged	Prepare new batteries	There is no battery capacity. Replace with new batteries.

Downloaded From camera-usermanual.com Samsung Manuals

Instructions on how to use the memory card

Maintenance of the memory card

- Be sure to format the memory card (see p.72) if you are using a newly purchased memory for the first time, if it contains data that the camera cannot recognize, or if it contains images captured with a different camera.
- Turn off the camera power whenever the memory card is being inserted or removed.
- Repeated use of the memory card will eventually reduce the memory card's performance. Should this be the case, you will need to purchase a new memory card. Wear and tear on the memory card is not covered by the Samsung warranty.
- The memory card is an electronic precision device. Do not bend, drop or subject the memory card to any heavy impact.
- Do not store the memory card in an environment with strong electronic or magnetic fields, e.g. near loud speakers or TV receivers.
- Please do not use or store in an environment where there are extremes in temperature.
- Do not allow the memory card to become dirty or to come into contact with any liquid. Should this happen, clean the memory card with a soft cloth.
- Please keep the memory card in its case when not in use.
- During and after periods of extended use, you may notice that the memory card is warm. This is perfectly normal.
- Do not use a memory card that is used in another digital camera. To use the memory card in this camera, format first the memory card by using this camera.
- Do not use a memory card formatted by another digital camera or memory card reader.

Preserving the memory card data

- If the memory card is subjected to any of the following, the recorded data may become corrupted :
  - When the memory card is used incorrectly.
  - If the power is switched off or the memory card is removed while recording, deleting (formatting) or reading.
- Samsung cannot be held responsible for lost data.
- It is advisable to copy important data onto other media as back-up e.g. floppy disks, hard disks, CD etc.
- If there is insufficient memory available : If you press the shutter button for the shot, a [CARD FULL !] message will appear and the camera will not operate. To optimize the amount of memory in the camera, replace the memory card or delete unnecessary images stored on the memory.

Downloaded From camera-usermanual.com Samsung Manuals

Instructions on how to use the memory card

INFORMATION

- If you open the battery chamber cover when the camera power is turned on, the power will turn off automatically.
- Don't remove the memory card when the camera status lamp(Green) is blinking as this may cause damage to data in the memory card.

■ The camera can use SD Memory Cards and MMC (Multi Media Card).



[SD(Secure Digital) memory card]

The SD memory card has a write protect switch that prevents image files from being deleted or formatted.
By sliding the switch to the bottom of the SD memory card, the data will be protected.
By sliding the switch to the top of the SD memory card, the data protection will be cancelled. Slide the switch to the top of the SD memory card before taking a picture.

■ When using a 16MB internal memory, the specified shooting capacity will be as follows. These figures are approximate as image capacities can be affected by variables such as subject matter.

Mode	STILL IMAGE mode					MOVIE CLIP mode	
Quality / Size	2272(P)	2048	1600(M)	1024	640(E)	640	320
SUPER FINE	10	13	17	38	81	-	-
FINE	20	27	37	78	145	-	-
NORMAL	33	42	50	113	234	-	-
15FPS	-	-	-	-	-	26SEC	1MIN11SEC
24FPS	-	-	-	-	-	18SEC	40SEC

Downloaded From camera-usermanual.com Samsung Manuals

Inserting the memory card

1. Turn off the camera's power and pull the battery chamber cover in the direction of the arrow to open.



2. Have the front of the memory card facing toward the back of the camera (LCD monitor) and the card pins toward the front of the camera (lens), and then push the memory card into the card slot until you hear a click.



3. To close, push the battery chamber cover until you hear a click. If the memory card does not slide in smoothly, do not attempt to insert it by force. Check the direction of insertion, and then insert it correctly. Do not insert the memory card the wrong way round. Doing so may damage the memory card slot.



Removing the memory card

1. Turn the power off using the power button.
   Open the battery chamber cover and press the memory card as shown in the image and release.

2. Remove the memory card and close the battery chamber cover.



Downloaded From camera-usermanual.com Samsung Manuals

LCD monitor indicator

■ The LCD monitor displays information about the shooting functions and selections.



[Image & Full Status]

No.	Description	Icons	Page
1	Battery		p.14
2	Recording mode		p.11~12 p.36
3	Continuous shot		p.40
4	Flash		p.26
5	Self-timer		p.28
6	Macro		
7	Metering		p.39
8	Card inserted indicator		
9	Camera shake warning		p.22
10	Date/ Time	2005/03/01 00:00AM	
11	Exposure compensation		p.32
12	White Balance	AWB	p.30

Downloaded From camera-usermanual.com Samsung Manuals

LCD monitor indicator

13	ISO	ISO AUTO / ISO 100 / ISO 200 / ISO 400	p.31
14	Sharpness		p.42
15	Image quality		p.38
16	Image size	2272, 2048, 1600, 1024, 640	p.37
17	Number of available shots remaining	20	
	Remaining time (Movie clip/ Voice recording)	00:01:11/ 00:25:50	
18	Voice memo		p.25
19	Digital Zoom rate	X4.0	

Starting the recording mode

■ If the memory card is inserted in the camera, all the camera functions apply only to the memory card. If the memory card is not inserted in the camera, all the camera functions apply only to the internal memory.

● Taking a still image

1. Insert the batteries (p.14). Insert the batteries taking note of the polarity (+ / -).
2. Insert the memory card. (p.17) As this camera has a 16MB internal memory, you do not need to insert the memory card. If the memory card is not inserted, an image will be stored in the internal memory. If the memory card is inserted, an image will be stored on the memory card.
3. Close the battery chamber cover.
4. Press the power button to turn on the camera.
5. Select the STILL IMAGE mode by pressing the mode button.
6. Point the camera towards the subject and compose the image by using the LCD monitor.
7. Press the shutter button to capture an image.



[STILL IMAGE mode]

Downloaded From camera-usermanual.com Samsung Manuals

Starting the recording mode

● Recording a Movie clip

Steps from 1-4 are the same as those for taking a still image.

5. Select the MOVIE CLIP mode by pressing the mode button.
6. Point the camera towards the subject and compose the image by using the LCD monitor.
7. Press the shutter button to take a movie clip. Press the shutter button once and movie clips are recorded for as long as the available recording time allows. Movie clips will still be recorded if the shutter button is released. If you wish to stop recording, press the shutter button again.
   - Image size : 640X480, 320X240 (Selectable)
   - File type : *. AVI(MJPEG)

[MOVIE CLIP mode]

● Pausing while recording a movie clip (Successive Recording)

This camera allows you to temporarily stop during unwanted scenes, while recording a movie clip. Using this function, you can record your favorite scenes into a movie clip without having to create multiple movie clips.

● Using Successive Recording

Steps from 1-6 are the same as those for MOVIE CLIP mode.

7. Press the shutter button and movie clips are recorded for as long as the available recording time. Movie clips will still be recorded if the shutter button is released.
8. Press the Pause button(▶/II) to pause recording.
9. Press the Pause button(▶/II) again to resume the recording.
10. If you wish to stop recording, press the shutter button again.



[Successive recording of a movie clip]

Downloaded From camera-usermanual.com Samsung Manuals

Starting the recording mode

■ How to use the VOICE RECORDING mode ( )

1. Select the VOICE RECORDING mode by pressing the Voice recording button twice. (In Movie clip mode, press the Voice recording button once to select the VOICE RECORDING mode)
2. Press the shutter button to record a voice.
   - Press the shutter button once and voice is recorded for as long as the available recording time (Max : 1 hour) allows. The recording time will be displayed on the LCD monitor. Voice will still be recorded if the shutter button is released.
   - If you wish to stop recording, press the shutter button again.
   - File type : *.WAV

   * A distance of 40cm between you and the camera (microphone) is the best distance to record sound.





[VOICE RECORDING mode]

● Pausing while recording a voice recording

This camera allows you to temporarily stop during unwanted recording, while recording a voice. Using this function, you can record your favorite voices into a voice recording file without having to create multiple voice recording files.

1. Press the shutter button and voice is recorded for as long as the available recording time. Voice will still be recorded if the shutter button is released.
2. Press the Pause button( ) to pause recording.
3. Press the Pause button( ) again to resume the recording.
4. If you wish to stop recording, press the shutter button again.



[Pausing the voice recording]

INFORMATION

● A distance of 40cm between you and the camera (microphone) is the best distance to record sound.

Downloaded From camera-usermanual.com Samsung Manuals

Things to watch out for when taking pictures

- When the Flash Off or Slow synchro mode is selected in a low lighting condition, the camera shake warning indicator ( ) may appear on the LCD monitor. In this case, use a tripod, support the camera on a solid surface or change the flash mode to flash shot mode.

- Backlight compensated shots : When taking an outdoor shot, avoid facing the sun, as the image may be dark because of the strong backlight. In backlight conditions, please use Fill-in flash(p.26), Spot metering(p.39) or Exposure compensation(p.32).

- Avoid obstructing the lens or the flash when you capture an image.

Downloaded From camera-usermanual.com Samsung Manuals

Using the camera buttons to adjust the camera

■ The RECORDING mode function can be set up by using the camera buttons.

POWER button



- Used for turning the camera's power on / off.
- If this camera isn't operated during the specified time(about 60 SEC.), the camera power will be idle(LCD monitor : OFF, Camera status lamp : ON) automatically.
  To use the camera again, press any of the camera buttons except the power button. If there is no operation during the specified time after the idle mode, the camera power will be turned off automatically to save battery life. Refer to page 70 for more information about the auto power off function.

SHUTTER button



- Used for taking an image or recording voice in the RECORDING mode.
- In MOVIE CLIP mode
  Pressing the shutter button down fully starts the process for recording a movie clip. Press the shutter button once and the movie clip is recorded for as long as the available recording time in the memory allows. If you wish to stop recording, press the shutter button again.
- In STILL IMAGE mode
  Pressing the shutter down fully takes the image and stores the relevant data regarding the shot. If you select voice memo recording, the recording will start after the camera has finished storing the image data.

Downloaded From camera-usermanual.com Samsung Manuals

ZOOM W/T button

● If the menu is not displayed, this button works as the DIGITAL ZOOM button.

● TELE Zoom

Digital zoom TELE : Pressing the ZOOM T button activates the digital zoom software. Releasing ZOOM T button stops the digital zooming at the required setting. Once the maximum digital zoom (4X) is achieved, pressing the ZOOM T button will have no effect. You can check the digital zoom rate with the [X1.1 ~ X 4.0] numerical mark next to the zoom bar.



[WIDE zoom] [Digital zoom 2.5X] [Digital zoom 4X]

● WIDE Zoom

Digital zoom WIDE : When the digital zoom is in operation, pressing the ZOOM W button will reduce the digital zooming in steps. Releasing ZOOM W button stops digital zooming.



[Digital zoom 4X] [Digital zoom 2.5X] [WIDE zoom]

INFORMATION

- To use the digital zoom the LCD monitor has to be turned on.
- Images taken using the digital zoom may take a little longer for the camera to process. Allow time for this to take place.
- The digital zoom cannot be used in movie clip shots.
- You may notice a decrease in image quality when using the digital zoom.

Downloaded From camera-usermanual.com Samsung Manuals

Voice memo( )/ UP button

■ While the menu is showing, press the UP button to move up the submenu cursor.

■ When the menu is not displayed on the LCD monitor, the UP button operates as the voice memo button. You can add your voice-over to a stored still image.

● Recording a voice memo

1. Select the STILL IMAGE mode by pressing the mode button.
2. Press the VOICE MEMO button. If the voice memo indicator is displayed on the LCD monitor, the setting is completed.



[Preparing for Voice Memo]

[Recording Voice Memo]

3. Press the shutter button and take a picture. The picture is stored on the memory card.
4. Voice memo will be recorded for ten seconds from the moment the picture is stored. In the middle of the sound recording, pressing the shutter button will stop the voice memo.

INFORMATION

- A distance of 40cm between you and the camera (microphone) is the best distance to record sound.
- The voice memo function will operate only once, and then it will automatically be cancelled.

Down button

■ While the menu is showing, press the DOWN button to move from the main menu to a submenu, or to move down the submenu cursor.

■ Unless the menu is showing, the DOWN button will not work in a Recording mode.

Downloaded From camera-usermanual.com Samsung Manuals

Flash ( ) / Left button

- When the menu is displayed on the LCD monitor, pressing the LEFT button makes the cursor shift to the left tab.
- When the menu is not displayed on the LCD monitor, the LEFT button operates as the FLASH ( ) button.

● Selecting the flash mode

1. Select the STILL IMAGE mode by pressing the mode button.
2. Press the Flash button until the desired flash mode indicator displays on the LCD monitor.
3. A flash mode indicator will be displayed on the LCD monitor. Use the correct flash to suit the environment.





[Selecting the auto flash]

● Flash range

Focus type	Flash range
Auto	1.0m ~ 2.5m
Macro	0.2m

INFORMATION

- Using the flash frequently will reduce the life of the batteries.
- Under normal operating conditions the charging time for the flash is normally within 5 seconds. If the batteries are weak, the charging time will be longer.
- During the continuous shot, movie clip mode, the flash function will not operate.
- Take photographs within the flash range.
- The image quality is not guaranteed if the subject is too close or highly reflective.

Downloaded From camera-usermanual.com Samsung Manuals

Flash ( ) / Left button

● Flash mode indicator

Icon	Flash mode	Description
	Auto flash	If the subject or background is dark, the camera flash will operate automatically.
	Auto & Red eye reduction	If a subject or background is dark, the camera flash will work automatically and will reduce the red-eye effect by using the red-eye reduction function.
	Fill in flash	The flash fires regardless of available light.
	Slow synchro	The flash will operate in conjunction with a slow shutter speed in order to obtain the correct exposure. We recommend using a tripod for this function. When you take an image in a condition with poor light, the camera shake warning indicator ( ) will display on the LCD monitor.
	Flash off	The flash does not fire. Select this mode when capturing images in a place or situation where flash photography is prohibited. When you capture an image in a poorly lit condition, the camera shake warning indicator ( ) will display on the LCD monitor.

● Available flash mode, by recording mode

		P					
	X	O	X	X	X	X	X
	O	O	X	X	O	X	X
	X	O	X	X	X	X	X
	X	O	X	O	X	X	X
	O	O	O	O	O	O	O

Downloaded From camera-usermanual.com Samsung Manuals

Self-timer ( ) / Right button

- When the menu is displayed on the LCD monitor, pressing the Right button makes the cursor shift to the right tab.
- When the menu is not displayed on the LCD monitor, the RIGHT button operates as the Selftimer( ) button. This function is used when the photographer would also like to be in the image.

● Selecting the self-timer

1. Select the MOVIE CLIP or STILL IMAGE mode by pressing the mode button.
2. Press the SELF-TIMER button until the desired mode indicator displays on the LCD monitor.
   A 2 second, 10 second or double self-timer icon appears on the LCD monitor. In Movie Clip mode, only the 10-second self-timer will work.
   - 2SEC self-timer ( ) :
     Pressing the shutter button will allow an interval of 2 seconds before the image is taken.
   - 10SEC self-timer ( ) :
     Pressing the shutter button will allow an interval of 10 seconds before the image is taken.
   - Double self-timer ( ) :
     A picture will be taken after about 10 seconds and 2 seconds later a second picture will be taken.
     When using the flash, the 2-second self-timer may be delayed for longer than 2 seconds depending on the flash charge time.
3. When you press the SHUTTER button, the picture will be taken after the specified time has elapsed.



[Selecting the 10 SEC self-timer]

INFORMATION

- When taking a picture using the self-timer, the self-timer lamp works as follows:
  - 2 second self-timer setting : The self-timer lamp blinks at 0.25 second intervals for 2 seconds.
  - 10 second self-timer setting : The self-timer lamp blinks at 1 second intervals for the first 7 seconds. It blinks at 0.25 second intervals for the remaining 3 seconds.
- If you operate the Power button, Self-timer button and shutter button during the self-timer operation, the self-timer function is cancelled.

Downloaded From camera-usermanual.com Samsung Manuals

MENU/ OK button

- When you press the MENU button, a menu related to each camera mode will be displayed on the LCD monitor. Pressing it again will return the LCD to the initial display.
- A menu option can be displayed when the following are selected : MOVIE CLIP and STILL IMAGE mode. There is no menu available when the VOICE RECORDING mode is selected.
- When the menu is displayed on the LCD monitor, this button is used for shifting the cursor to the sub menu or for confirming data.



[Menu off] [Menu on]

INFORMATION

- The menu will not be displayed on the LCD monitor in the following circumstances:
  - When another button is being operated.
  - While image data is being processed.
  - When there is no battery capacity.

Downloaded From camera-usermanual.com Samsung Manuals

+/- button

■ You can use the +/- button to adjust the values for the white balance, ISO, exposure compensation, shutter speed and aperture value.

Main menu	Sub menu	Available camera mode
WHITE BALANCE	AUTO, DAYLIGHT, CLOUDY, SUNSET, FLUORESCENT H, FLUORESCENT L, TUNGSTEN, CUSTOM.	P
Exposure compensation	-2.0 ~ 0.0 ~ +2.0 (0.5EV steps)	P
ISO	AUTO, 100, 200, 400	P
Aperture value Shutter speed	Shutter speed : 8 ~ 1/1,000 Sec. Aperture value : F 3.5 / F 7.0	

■ White balance : The white balance control allows you to adjust the colours to appear more natural looking.

● Selecting a White Balance



1. Press the +/- button, and then use the UP and DOWN buttons to select the white balance icon (AWB). The white balance menu bar will appear as shown.
2. Use the LEFT and RIGHT buttons to set the white balance to the desired value. The value you set will be displayed on the LCD monitor.

AUTO AWB : The camera automatically selects the appropriate white balance settings, depending on the prevailing lighting conditions.

DAYLIGHT : For taking images outside.

CLOUDY : For taking images under a cloudy and overcast sky.

SUNSET : For taking images at sunset.

FLUORESCENT H : For shooting under daylight fluorescent types of three-way fluorescent lighting.

FLUORESCENT L : Shooting under white fluorescent lighting.

TUNGSTEN : For shooting under tungsten (standard light bulb) lighting.

CUSTOM : Allows the user to set the white balance according to the shooting condition.

Different lighting conditions may cause a colour cast on your images.

3. Press the +/- button again. The value you set will be saved and White Balance setup mode will end.

Downloaded From camera-usermanual.com Samsung Manuals

+/- button

● Using the Custom White Balance

White balance settings may vary slightly depending on the shooting environment.
You can select the most appropriate white balance setting for a given shooting environment by setting up the custom white balance.

1. Select the CUSTOM (▂■▂) menu of the White Balance and press the OK button.
2. Place a sheet of white paper in front of the camera so that the LCD monitor shows only white, and then press the SHUTTER button.
3. Press the OK button and your custom white balance value is stored.
   - The custom white balance value will be applied, starting with the next picture you take.
   - The user configured white balance will be remain effective until it is overwritten.

※ The OK button written in this manual means the MENU button.





[White paper]

■ ISO: You can select the ISO sensitivity when taking pictures.
The speed or specific light-sensitivity of a camera is rated by ISO numbers.

● Selecting an ISO Sensitivity

1. Press the +/- button, and then use the UP and DOWN buttons to select the ISO icon(ISO AUTO). The ISO menu bar will appear as shown.
2. Use the LEFT and RIGHT buttons to select the desired ISO sensitivity value.

- AUTO:
  The camera's sensitivity is automatically changed by variables such as lighting value or subject brightness.
- 100, 200, 400:
  You can increase the shutter speed while the same amount of light is present, by increasing the ISO sensitivity. However, the image may be saturated in high luminance. The higher the ISO value, the higher the camera's sensitivity to light is and therefore the greater its capacity to take pictures in dark conditions. However, the noise level in the image will increase as the ISO value increases, making the image appear coarse.

3. When you press the +/- button again, the value you set will be saved and ISO setup mode will end.

Downloaded From camera-usermanual.com Samsung Manuals

+/- button

■ Exposure compensation

: This camera automatically adjusts the exposure according to the ambient lighting conditions. You can also select the exposure value by using the +/- button.

● Compensating Exposure



1. Press the +/- button, and then use the UP and DOWN buttons to select the exposure compensation icon ( ). The exposure compensation menu bar will appear as shown.
2. Use the LEFT and RIGHT buttons to set the desired exposure compensation factor.
3. Press the +/- button again. The value you set will be saved and the Exposure Compensation setup mode will close. If you change the exposure value, the exposure indicator ( ) will be displayed on the bottom of the LCD monitor.

* A negative exposure compensation value reduces the exposure.
Note that a positive exposure compensation value increases the exposure and the LCD monitor will appear white or you may not get good pictures.

■ Setting up the shutter speed and aperture value

: This camera automatically adjusts the shutter speed and aperture values to the shooting environment. However, in Night scene mode, you can set the shutter speed and aperture values to your preference.

1) Selecting the Night scene Mode



1. Select the STILL IMAGE mode by pressing the mode button.
2. Press the MENU button.
3. Use the LEFT and RIGHT buttons to select the [MODE] menu tab.
4. Press the UP and DOWN buttons to select the [SCENE] menu and press the RIGHT button.
5. Press the UP and DOWN button to select the [NIGHT] menu.
6. Press the MENU button. The menu will disappear and the mode will switch to Night scene mode.

Downloaded From camera-usermanual.com Samsung Manuals

+/- button

2) Setting up the shutter speed and aperture value

1. In night scene mode, press the +/- button.
   A screen appears as shown to the right.
2. Use the LEFT and RIGHT buttons to set the shutter speed. Use the UP and DOWN buttons to set the aperture value.
3. Press the +/- button again. The value you set will be saved and the mode will switch to Night scene mode. Press the SHUTTER button to take the picture.

LCD button

■ You can check the recording status in the LCD monitor. Pressing the LCD button in the RECORDING (STILL IMAGE, MOVIE CLIP) mode will change the display as shown below.





■ If the LCD monitor is turned off, the camera status lamp will light up.

Downloaded From camera-usermanual.com Samsung Manuals

Using the LCD monitor to adjust the camera settings

■ You can use the menu on the LCD monitor to set up recording functions. In any mode with the exception of VOICE RECORDING mode, pressing the MENU button displays the menu on the LCD monitor.

INFORMATION

- The menu will not be displayed on the LCD monitor in the following circumstances:
  - When another button is being operated.
  - While image data is being processed.
  - When there is no battery capacity.
- The OK button written in this manual means the MENU button.

■ The following functions are available, depending on the mode you have selected.

The items indicated by [ ] are default settings.

Menu tab	Main menu	Sub menu		Camera working mode	Page
	MODE	AUTO			p.36
		PROGRAM			
		SCENE	NIGHT		
			PORTRAIT		
			LANDSCAPE		
			FIREWORKS		
	SIZE	2272X1704(P)			p.37
		2048X1536			
		1600X1200(M)			
		1024X768			
		640X480(E)			
		640X480			
		320X240			
	QUALITY	S.FINE			p.38
		FINE			
		NORMAL			
		15FPS			
		24FPS			
	METERING	MULTI			p.39
		SPOT			

Downloaded From camera-usermanual.com Samsung Manuals

Using the LCD monitor to adjust the camera settings

Menu tab	Main menu	Sub menu		Camera working mode	Page
	SHOOTING	SINGLE		P	p.40
		2, 4, 8 SHOTS			
	EFFECT	NORMAL		P	p.40
		B&W			
		SEPIA			
	P.FRAME	OFF		P	p.41
		1~9			
	SHARPNESS	SOFT		P	p.42
		NORMAL			
		VIVID			
	MYSET	LOAD	CANCEL	P	p.43
			MYSET1,2,3		
		SAVE	MYSET1,2,3		

* Menus are subject to change without prior notice.

Downloaded From camera-usermanual.com Samsung Manuals

How to use the menu

1. Turn on the camera and press the MENU button. A menu for each camera mode appears. However, there is no menu for Voice Recording mode ( ).
2. Use the LEFT and RIGHT buttons to navigate through the menus.

3. Use the UP and DOWN buttons to select a sub menu.

4. Select a sub menu, and then the value you set will be saved. Press the MENU button and the menu will disappear.

Mode

■ You can select the desired Still Image mode.

[AUTO] : Use this for shooting basic still images.

[PROGRAM] : Selecting the automatic mode will configure the camera with optimal settings. You can still manually configure all functions except the aperture value and shutter speed.

[SCENE] : Use the menu to easily configure optimal settings for a variety of shooting situations.

[NIGHT] - Use this for shooting still images at night or in other dark conditions.

[PORTRAIT] - To take picture of a person.

[LANDSCAPE] - Scenery with green woods or blue sky.

[FIREWORKS] - Firework scenes.

[STILL IMAGE mode]

* When [NIGHT], [FIREWORKS] scene mode are selected, it is possible that camera shake will occur. If you think this will happen, use a tripod.

Downloaded From camera-usermanual.com Samsung Manuals

Size

■ You can select the image size appropriate for your application.

Mode	STILL IMAGE mode					MOVIE CLIP mode	
Icon	2272	2048	1600	1024	640	640	320
Size	2272X1704	2048X1536	1600X1200	1024X768	640X480	640X480	320X240



[STILL IMAGE mode]



[MOVIE CLIP mode]

INFORMATION

- The higher the resolution, the lower the number of available shots will be because high resolution images require more memory than lower resolution images.
- The selectable image sizes in the AUTO mode are listed below.
  - P(2272X1704) : For printing the image
  - M(1600X1200) : For saving the image to a PC
  - E(640X480) : For sending the image by e-mail

Downloaded From camera-usermanual.com Samsung Manuals

Quality

■ You can select the compression ratio appropriate for your application of the captured images. The higher the compression ratio, the lower the picture quality.

Mode	STILL IMAGE mode			MOVIE CLIP mode	
Icon				15F	24F
Sub menu	S.FINE	FINE	NORMAL	15FPS	24FPS
File Format	jpeg	jpeg	jpeg	avi	avi



[STILL IMAGE mode]



[MOVIE CLIP mode]

● When using a 16MB internal memory, the specified shooting capacity will be as follows. These figures are approximate as image capacities can be affected by variables such as subject matter.

Mode	STILL IMAGE mode					MOVIE CLIP mode	
Quality/Size	2272	2048	1600	1024	640	640	320
S. FINE	10	13	17	38	81	-	-
FINE	20	27	37	78	145	-	-
NORMAL	33	42	50	113	234	-	-
15FPS	-	-	-	-	-	26SEC	1MIN11SEC
24FPS	-	-	-	-	-	18SEC	40SEC

INFORMATION

- S.FINE is the highest quality and NORMAL is the lowest setting. Choose the setting appropriate for your needs.
- This file format complies with the DCF(Design rule for Camera File system).
- JPEG (Joint Photographic Experts Group) : JPEG is the image compression standard developed by the Joint Photographic Experts Group. This type of compression is most commonly used for compressing photos and graphics because it can compress the files efficiently without damaging the data.

Downloaded From camera-usermanual.com Samsung Manuals

Metering

■ If you cannot obtain suitable exposure conditions, you can change the metering method to take brighter pictures.

[MULTI](▣) : Exposure will be calculated based on an average of the available light in the image area. However, the calculation will be biased towards the centre of the image area. This is suitable for general use.



[PROGRAM mode]

[SPOT] (⊙) : The indicated area at the center will be metered, as shown on the right. This is suitable when the subject at the center is exposured correctly regardless of back lighting.

[Spot metering zone]

INFORMATION

● If the subject is not the centre of the focus area, do not use the spot metering as this may result in an exposure error. In this circumstance, rather use exposure compensation.

Downloaded From camera-usermanual.com Samsung Manuals

Continuous shot

■ Select the number of pictures in continuous shooting.

- [SINGLE] : Take one picture only
- [2, 4, 8 SHOTS] : Take the set number of pictures with one push of the shutter. Continuous shooting mode is cleared after one shooting.

[PROGRAM mode]

● Available maximum number of continuous shots, by image size/ quality type

size \ quality	S.FINE	FINE	NORMAL
2272X1704	2	2	2
2048X1536	2	2	2
1600X1200	2	2	4
1024X768	4	8	8
640X480	8	8	8

* High resolution and picture quality increases file saving time, which increases stand-by time.
* If the [2, 4, 8 SHOTS] sub menu is selected, the flash will be off automatically.
* If you change the image size and quality after selecting the number of continuous shots, the [SHOOTING] sub menu will be changed to the [SINGLE] automatically.

Effect

■ By using the camera's digital processor, it is possible to add special effects to your images.



[PROGRAM mode]



[MOVIE CLIP mode]

NORMAL : No effect is added to the image.
B & W : Converts the image to black and white.
SEPIA : Captured images will be stored in a sepia tone (a gradient of yellowish brown colours).

Downloaded From camera-usermanual.com Samsung Manuals

Photo Frame

■ You can add 9 types of frame-like borders to a still image you want to capture.

- If you select the [OFF] sub menu in the [P.FRAME] menu or turn on and off the camera in the PROGRAM mode, the selected photo frame will be cancelled.
- Available photo frames are as follows:



[PROGRAM mode]

[FRAME 1]

[FRAME 2]

[FRAME 3]



[FRAME 4]

[FRAME 5]

[FRAME 6]

[FRAME 7]



[FRAME 8]



[FRAME 9]

Downloaded From camera-usermanual.com Samsung Manuals

Sharpness

■ You can adjust the sharpness of the picture you want to take. You cannot check the sharpness effect on the LCD monitor before you take a picture, because this function is applied only when the captured image is stored on the memory.

[PROGRAM mode]

Sub menu	Icon	Description
SOFT		The edges of the image are softened. This effect is suitable for editing images on your PC.
NORMAL		The edges of the image are sharp. This is suitable for printing.
VIVID		The edges of the image are emphasized. The edges will appear sharp, but noise may occur in the recorded image.

Downloaded From camera-usermanual.com Samsung Manuals

Save / Load the camera configuration (MYSET)

■ Use the MYSET mode to save frequently used camera settings (SAVE) and use it later (LOAD)

● Saving the camera configuration: Available in the PROGRAM mode.

1. Press the MENU button and select [MYSET] menu by pressing the LEFT/RIGHT button.
2. Press the UP/DOWN buttons to select the [SAVE] menu and press the right button.
3. Press the UP/DOWN buttons to select desired MYSET slot number to save.
4. Press the OK button to save the current configuration in the selected MYSET slot.



[PROGRAM mode]

● Loading the saved camera configuration: available in the PROGRAM mode.

1. Press the MENU button and select [MYSET] menu by pressing the LEFT/RIGHT button.
2. Press the UP/DOWN buttons to select the [LOAD] menu and press the right button.
3. Press the UP/DOWN buttons to select desired MYSET slot number to load.
4. Press the OK button to set the camera configuration as saved in the MYSET slot.



[PROGRAM mode]

* The current MYSET slot number is displayed in the top left of the LCD.
* If you select [CANCEL] in the [LOAD] menu or turn on and off the camera in the MYSET mode, the MYSET mode will be cancelled.

Downloaded From camera-usermanual.com Samsung Manuals

LCD monitor indicator

■ The LCD monitor displays information about the shooting conditions.



No.	Description	Icon	Page
1	Battery		p.14
2	Play mode		
3	File Type		
4	Voice memo		p.48
5	Protect indicator		p.58
6	DPOF indicator		p.59
7	Stored image number	100-0009	

■ If you press the LCD button, you can check the following recording information:



SIZE	: 2272X1704	Size
AV	: F3.5	Aperture value
TV	: 1/18	Shutter speed
FLASH	: OFF	Whether or not the flash is used.
DATE	: 2005/03/01	Recording date

Downloaded From camera-usermanual.com Samsung Manuals

Starting play mode

- If the memory card is inserted in the camera, all the camera functions apply only to the memory card.
- If the memory card is not inserted in the camera, all the camera functions apply only to the internal memory.
- If you have turned on the camera by pressing the POWER button, you can press the PLAY MODE button once to switch to Play mode and press it again to switch to Recording mode.
- You can set up the PLAY mode function by using the camera buttons and LCD monitor.

● Playing back a still image

1. Select the PLAY mode by pressing the play mode button (▣).

2. The last image stored on the memory is displayed on the LCD monitor.

3. Select an image that you want to play back by pressing the LEFT / RIGHT button.

※ Press and hold the LEFT or RIGHT button to fast forward the images played.



INFORMATION

- Press the shutter button in Play mode to switch to the currently set shooting mode.
- The OK button written in this manual means the MENU button.

Downloaded From camera-usermanual.com Samsung Manuals

Starting play mode

● Playing back a movie clip

Steps from 1-2 are the same as those to play back a still image.

3. Select the recorded movie clip that you want to play back by using the LEFT/RIGHT button. If you select a movie clip, the movie clip indicator ( ) will be displayed on the LCD monitor.
4. Press the play & pause button ( ) to play back a movie clip file.
   - To pause a movie clip file while playing it back, press the play & pause button again.
   - Pressing the play & pause button again will cause the movie clip file will restart.
   - To rewind the movie clip while it is playing, press the LEFT button. To fast forward the movie clip, press the RIGHT button.
   - To stop playback of the movie clip, press the play & pause button, and then press the LEFT or RIGHT button.



● Playing back a recorded voice

In order to play back voice files recorded with the camera, the camera must be connected to your PC (See p.95). Your PC must have a sound card and speakers installed. Please be sure to install the camera driver before connecting the camera to your PC.

1. Connect the camera to your PC.
2. Open Windows Explorer and open the DICM/100SSCAM folder of the Removable Drive.
3. Select a voice file (*.wav).
4. Right-click and select [Copy].
5. Select the folder on your PC to which you want to save the file, right-click, and select [Paste].
6. Click on the file you just saved. The player will appear on the left side of the Explorer window.
7. Click on the Play button to play back the voice file.

* The method of playing back voice memos added to still images is the same as the method of playing back voice files.

[Play Button]

Downloaded From camera-usermanual.com Samsung Manuals

Using the camera buttons to adjust the camera

■ In Play mode, you can use the buttons on the camera to conveniently set up the Play mode functions.

Thumbnail( ) / Enlargement( ) button

- You can view multiple pictures, enlarge a selected picture, and crop and save a selected area of an image.
- Thumbnail display
  1. While an image is displayed full screen, press the thumbnail button.
  2. The thumbnail display will highlight the image that had been showing at the time the thumbnail mode was selected.
  3. Press the 5 function button to move to a desired image.
  4. To view an image separately, press the enlargement button.





[Normal display mode]

Pressing the thumbnail button( )

Pressing the enlargement button( )

Highlighted image

[Thumbnail display mode]

- Image enlargement
  1. Select an image that you want to enlarge and press the enlargement button.
  2. Different parts of the image can be viewed by pressing the 5 function button.
  3. Pressing the thumbnail button will zoom back to the original full sized image.
  - You can tell whether the image displayed is an enlarged view by checking the image enlargement indicator shown at the bottom left of the LCD monitor. (If the image is not an enlarged view, the indicator will not be displayed.) You can also check the area of enlargement.
  - Movie clips and WAV files can't be enlarged.
  - If an image is enlarged, a loss of quality may occur.





Downloaded From camera-usermanual.com Samsung Manuals

Thumbnail( ) / Enlargement( ) button

● The maximum enlargement rate in proportion to the image size.

Image size	2272	2048	1600	1024	640
Maximum enlargement rate	X7.0	X5.0	X3.0	X2.0	X2.0

● Trimming : You can extract part of the image that you want and save it separately.

1. Select an image that you want to enlarge and press the enlargement button.
2. Different parts of the image can be viewed by pressing the 5 function button.
3. Press the MENU button and a message will be displayed as shown alongside.
4. Select the submenu values by pressing the UP/DOWN button and then press the OK button.

   TRIM : trimmed images are saved in their last file names.

   CANCEL : cancels trimming.

※ If there is little memory space to save the trimmed image, the image can' t be trimmed.

Voice ( ) memo / Up button

■ When the menu is displayed on the LCD monitor, pressing the UP button makes the menu cursor move up.

■ When the menu is not displayed on the LCD monitor, the UP button operates as the voice memo button. You can add your audio to a stored still image.

● Adding a Voice Memo to a Still Image

1. Press the LEFT/ RIGHT button to select an image that you wish to add sound to.
2. Press the voice memo button ( ) and the voice memo indicator will display. The camera is now ready to record a voice memo.

Downloaded From camera-usermanual.com Samsung Manuals

Voice ( ) memo / Up button

3. Press the shutter button to start recording and voice will be recorded to the still image for 10 seconds.
   While the voice is recording, the recording status window will be displayed as shown alongside.



4. The recording can be stopped by pressing the shutter button again.

5. The ( ) icon will be displayed on the LCD monitor after voice memo recording has finished.
   - Voice memos can't be recorded onto movie clip files.
   - A distance of 40cm between you and the camera (microphone) is the best distance to record sound.
   - The voice memo will be saved in *.wav format, but has the same file name as the still image to which it corresponds.
   - If you add a new voice memo to the still image that already has a voice memo, the existing voice memo will be erased.



Play & Pause ( ) / Down button

■ In play mode, the play & pause/ down button works as follows:
- If the menu is displayed
  Press the DOWN button to move from the main menu to a sub menu, or to move down the sub menu cursor.
- If a movie clip is playing
  In Stop mode : Plays a movie clip
  During playback : Temporarily stops playback
  In Pause mode : Resumes playback

[Movie clip is stopped]



[Movie clip is playing]

[Movie clip is paused]

Downloaded From camera-usermanual.com Samsung Manuals

LEFT/ RIGHT/ MENU/ OK button

■ LEFT / RIGHT/ MENU/ OK buttons activate the following.

- LEFT button : While the menu is showing, press the LEFT button to select the menu tab to the left of the cursor.
- RIGHT button : While the menu is showing, press the RIGHT button to select the menu tab to the right of the cursor, or to move an secondary menu.
- MENU button : When you press the MENU button, the play mode menu will be displayed on the LCD monitor. Pressing it again will return the LCD to the initial display.
- OK button : When the menu is displayed on the LCD monitor, the OK button is used for confirming data that is changed by using the 5 function button.

LCD ( ) button

■ The shooting information will be displayed on the LCD monitor.
The last image stored in the memory is displayed on the LCD monitor by pressing the play mode button. Pressing the LCD( ) button in the PLAY mode will change the display as shown below. [Image & Icons] → [Image & Information] → [Image only]



Downloaded From camera-usermanual.com Samsung Manuals

Delete( ) button

■ This deletes images stored on the memory card.

● Deleting Images in Play Mode

1. Select an image that you want to delete by pressing the LEFT / RIGHT button and press the DELETE( ) button.



2. A message will display as shown alongside on the LCD monitor.
3. Select the submenu values by pressing the UP/DOWN button and then press the OK button.
   If [DELETE] is selected : deletes the selected images.
   If [CANCEL] is selected : cancels "Delete Image"

● Deleting Images in Thumbnail Display Mode

1. Use the UP, DOWN, LEFT, and RIGHT buttons to select the image you want to delete, and then press the DELETE button.
2. The following message will be displayed on the LCD monitor.



3. Select the submenu values by pressing the UP/DOWN button and then press the OK button.
   If [DELETE] is selected : deletes the selected images.
   If [CANCEL] is selected : cancels "Delete Image"

INFORMATION

● Before deleting images from the camera, you should protect or download images to your computer that you wish to keep.

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the play back function using the LCD monitor

- PLAY mode functions can be changed by using the LCD monitor. In the PLAY mode, pressing the MENU button displays the menu on the LCD monitor. The menus you can set up in Play mode are as follows. To capture an image after setting up the play menu, press the PLAY button or shutter button.
- The OK button written in this manual means the MENU button.

Menu tab	Main menu	Sub menu	Secondary menu	Page
	SLIDE	INTERVAL	1, 3, 5, 10SEC	p.55
		REPEAT	OFF / ON	
		START		
	ROTATE	RIGHT90	-	p.56
		LEFT90	-	
		180	-	
		HORIZONTAL	-	
		VERTICAL	-	
	RESIZE	2048X1536	-	p.57
		1600X1200	-	
		1024X768	-	
		640X480	-	
		LOGO	-	
	PROTECT	ONE PIC	UNLOCK / LOCK	p.58
		ALL PICS	UNLOCK / LOCK	
	DELETE ALL	NO	-	p.59
		YES	-	
	DPOF	STANDARD	ONE PIC/ ALL PICS	p.59 ~ p.61
		INDEX	NO/ YES	
		SIZE	DEFAULT/3X5/4X6/5X7/8X10	
		CANCEL	STANDARD/INDEX/SIZE	
	COPY TO CARD	NO	-	p.62
		YES	-	

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the play back function using the LCD monitor

■ This menu is available while the camera is connected to a PictBridge supporting printer (direct connection to the camera, sold separately) with a USB cable.

Menu tab	Main menu	Sub menu	Secondary menu	Page
	IMAGES	ONE PIC	-	p.64
		ALL PICS	-	
	PRINT	STANDARD	-	p.65
		INDEX	-	
	DPOF PRINT	NO	-	p.65
		YES	-	
	AUTO SET	NO	-	p.66
		YES	-	
	CUSTOM SET	SIZE	AUTO	p.66
			POSTCARD	
			4X6	
			2L	
			A4	
			LETTER	
			A3	
		LAYOUT	AUTO	
			INDEX	
			FULL	
			1	
			2	
			4	
			6	
			8	

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the play back function using the LCD monitor

Menu tab	Main menu	Sub menu	Secondary menu	Page
	CUSTOM SET	TYPE	AUTO	p.66
			PLAIN	
			PHOTO	
			FAST PHO.	
		QUALITY	AUTO	
			DRAFT	
			NORMAL	
			FINE	
		DATE	AUTO	
			OFF	
			ON	
		FILE NAME	AUTO	
			OFF	
			ON	
	RESET	NO	-	p.67
		YES	-	

※ Menus are subject to change without prior notice.

Downloaded From camera-usermanual.com Samsung Manuals

Starting the slide show

■ Images can be displayed continuously at pre-set intervals.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [SLIDE] menu tab.



● Setting play interval: Set the slide show play interval.

1. Use the Up/Down buttons to select the [INTERVAL] menu and press the Right button.
2. Use the Up/Down buttons to select the desired interval.
3. Press the OK button to save the configuration.

● Repeat setting : Repeat or not the slide show after finishing the first cycle.

1. Use the Up/Down buttons to select the [REPEAT] menu and press the Right button.
2. Use the Up/Down buttons to select the desired sub menu.
   [OFF] Selected : The slide show is closed after one cycle.
   [ON] selected : The slide show is repeated until cancelled.
3. Press the OK button to save the configuration.

● Start the slide show: The slide show can start only in the [START] menu.

1. Use the Up/Down buttons to select the [START] menu.
2. Press the OK button to start the slide show.
   - Press the Pause button to pause the slide show.
   - Press the Pause button (▶/II) again to resume the slide show.
   - Press the Menu button to stop the slide show.

INFORMATION

- The loading time depends on the image size and quality.
- While the slide show is playing, only the first frame of a movie file is displayed. In case of a voice file, the voice recording icon will appear.

Downloaded From camera-usermanual.com Samsung Manuals

Rotating an image

■ You can rotate the stored images by various degrees.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [ROTATE] menu tab.
3. Select a desired sub menu by pressing the UP/ DOWN button.



[RIGHT 90] :
Rotate picture in a clock-wise direction

[LEFT 90] :
Rotate picture in a counter-clock-wise direction



[180] :
Rotate picture 180 degrees



[HORIZONTAL] :
Rotate picture horizontally



[VERTICAL] :
Rotate picture vertically

4. Press the OK button. The rotated image will be saved with a new file name and the menu will disappear. If you display the rotated image on the LCD monitor, empty spaces may appear to the left and right of the image.

Downloaded From camera-usermanual.com Samsung Manuals

Resize

■ Change the resolution (size) of pictures taken. Select [LOGO] to save an image to be the start-up image. The resized image will have a new file name.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [RESIZE] menu tab.
3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

● Image Resize Types

Resize	2048X 1536	1600X 1200	1024X 768	640X 480	LOGO
2272	O	O	O	O	O
2048	X	O	O	O	O
1600	X	X	O	O	O
1024	X	X	X	O	O
640	X	X	X	X	O

INFORMATION

- A large sized image can be resized to a smaller sized image, but not vice versa.
- Only JPEG images can be resized. MOVIE and WAV files can't be resized.
- You can change the resolution of only those files compressed in the JPEG 4:2:2 format.
- The resized image will have a new file name. The [LOGO] image is stored not on the memory card but on the internal memory.
- Only one [LOGO] image can be saved. If you save a new [LOGO] image, the existing startup image will be deleted.
- If the memory capacity is insufficient to store the resized image, a [CARD FULL!] message will display on the LCD monitor and the resized image will not be stored.

Downloaded From camera-usermanual.com Samsung Manuals

Protecting images

■ This is used to protect specific shots from being accidentally erased (LOCK).
It also unprotects images that have been previously protected (UNLOCK).

● Protecting Images

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [PROTECT] menu tab.
3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   [ONE PIC] : Only an image that is displayed on the LCD monitor is protected or unprotected.
   [ALL PICS] : All of the stored images are protected or unprotected.
4. Select the desired secondary menu by pressing the UP/DOWN button and press the OK button.
   [UNLOCK] : Cancels the protect function.
   [LOCK] : Sets up the protect function.
   - If you select the[ONE PIC] sub menu at step 3, you can protect or unprotect another image by pressing the LEFT/ RIGHT button. If you press the SHUTTER button, the Image Protection menu will disappear.
   - If you selected [ALL PICS] in Step 3, the Image Protection menu will disappear.
   - If you protect an image, the protect icon( ) will be displayed on the LCD monitor. (An unprotected image has no indicator)
   - An image in LOCK mode will be protected from [DELETE] or [DELETE ALL] functions, but will NOT be protected from the [FORMAT] function.

Downloaded From camera-usermanual.com Samsung Manuals

Deleting all images

■ Of all the files stored in the memory card, the unprotected files in the DCIM subfolder will be deleted. Remember that this will permanently delete unprotected images. Important shots should be stored on a computer before deletion takes place. The startup image is stored in the camera's internal memory (i.e., not on the memory card) and it will not be deleted even if you delete all files on the memory card.

● Deleting all images

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DELETE ALL] menu tab.
3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   Selecting [NO] : Cancels “Delete All”
   Selecting [YES] : Displays the dialogue box to confirm the delete.

- If [DELETE] is selected : press the OK button and all unprotected pictures are deleted.
- If [CANCEL] is selected : press the OK button and images are not deleted.

DPOF

■ DPOF(Digital Print Order Format) allows you to embed printing information on your memory card’s MISC folder. Select the pictures to be printed and how many prints to make.
■ The DPOF indicator will display on the LCD monitor when an image that has DPOF information plays back. Images can then be printed on DPOF printers, or at an increasing number of photo labs.
■ This function is not available for Movie clips and Voice recording files.
■ When this menu is selected without inserting a memory card, you can't select the [DPOF] sub menu.

Downloaded From camera-usermanual.com Samsung Manuals

DPOF : STANDARD

■ This function allows you to embed print quantity information on a stored image.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [STANDARD] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the UP and DOWN buttons to select [ONE PIC] or [ALL PICS], and then press the OK button. A window for selecting number of copies.
   [ONE PIC] : Set the number of copies to print for the current picture only.
   [ALL PICS] : Set the number of copies to print for each picture, excluding movie clips and voice recordings.
5. Use the UP and DOWN buttons to select the number of copies and then press the OK button.
   - The DPOF icon ( ) will appear by the pictures for which the number of copies to print is set.



DPOF : INDEX

■ Images (except for movie clips and voice file) are printed as index type.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [INDEX] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button.
   If [NO] is selected : The image will not be printed in index format.
   If [YES] is selected : The image will be printed in index format.
5. Press the OK button to confirm the setting.

Downloaded From camera-usermanual.com Samsung Manuals

DPOF : PRINT SIZE

■ You can specify the print size when printing images stored on the memory card.
The [SIZE] menu is available only for DPOF 1.1 compatible printers.

● Setting the Print Size



1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [SIZE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

* SIZE : DEFAULT, 3X5, 4X6, 5X7, 8X10
* The [DEFAULT] print size varies depending on the printer manufacturer.
For your printer's default value, please refer to the user's guide that came with your printer.

DPOF : CANCEL

■ You can cancel the [STANDARD], [INDEX], or [SIZE] settings. Cancel the setting to reset the value to its default.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [CANCEL] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button.
   If [STANDARD] is selected : Cancels the standard print setting.
   If [INDEX] is selected : Cancels the index print setting.
   If [SIZE] is selected : Cancels the print size setting.
5. Press the OK button to confirm the setting.

Downloaded From camera-usermanual.com Samsung Manuals

COPY TO CARD

■ This enables you to copy image files to the memory card.

● Copying to the Memory Card

1. Press the play mode button and press the menu button.
2. Select the [COPY TO CARD] menu tab by pressing the LEFT/ RIGHT button.
3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   - [NO] : Cancels "COPY TO CARD".
   - [YES] : All images saved in the internal memory are copied to the memory card after the [PLEASE WAIT!] message is displayed. After copying has been completed, the screen will return to play mode.



INFORMATION

- When this menu is selected without inserting a memory card, you can't select the [COPY TO CARD] sub menus.
- If there is not enough space available in the memory card to copy saved images in the internal memory (16MB), the [COPY TO CARD] command will copy only some of the images and display [CARD FULL!] message. Then the system will return to the playback mode. Please be sure to delete any unnecessary images to free up space before inserting the memory card into the camera.
- When you move the images that are stored in the internal memory by doing [COPY TO CARD] to the card, 101SSCAM folder will be created in the card to avoid duplication of the sub folder name. Whenever you carry out the [COPY TO CARD] function, the number of SSCAM folder increases. (Ex : 100SSCAM, 101SSCAM, 102SSCAM, 103SSCAM...) After completing [COPY TO CARD], the last stored image of the last copied folder is displayed on the LCD monitor. When you take an image, the image is stored in the last copied folder.

Downloaded From camera-usermanual.com Samsung Manuals

PictBridge

■ You can use the USB cable to connect this camera to a printer that supports PictBridge (sold separately) and print the stored images directly. Movie clips and voice files cannot be printed. You can set up the following settings from the PictBridge menu.

IMAGES	: Select the pictures to be printed.
PRINTER SETUP	: Setting up printing(AUTO SET/CUSTOM SET)
PRINT	: Printing pictures
DPOF PRINT	: Printing the DPOF files
RESET	: Initializing the PictBridge functions

● Connecting the Camera to a Printer

1. Press the power button to turn the camera power on.
2. In a mode other than Voice Recording mode, press the MENU button.
3. Press the LEFT/ RIGHT button and select [SETUP] menu tab.
4. Select [USB] menu by pressing the UP/ DOWN button and press the RIGHT button.
5. Select [PRINTER] menu by pressing the UP/ DOWN button and press the OK button.
6. Press the menu button twice and the menu will disappear.
7. Use the supplied USB cable to connect the camera to the printer as shown below.
8. Turn on the printer to connect the camera to the printer.





※ If you selected [COMPUTER] in Step 5, when you connect the camera to your printer, the camera status lamp(Green) will illuminate and the connection will not be established. In this case, disconnect the USB cable, and then follow the procedure from Step 2 and onward.

Downloaded From camera-usermanual.com Samsung Manuals

PictBridge: Picture Selection

■ Select pictures to print

1. Connect the camera to your printer. The USB menu must be set to [PRINTER] before you connect the camera to the printer.(See p.63)
2. The [IMAGES] menu will appear.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.



When [ONE PIC] is selected : The PictBridge function will be applied only to the picture currently displayed.

When [ALL PICS] is selected : The PictBridge function will be applied to all pictures, excluding movie clips and voice files.

● Setting the Number of Copies to Print

- Select [ONE PIC] or [ALL PICS]. A screen where you can set the number of copies to print will appear as shown below.



[When [ONE PIC] is selected]



[When [ALL PICS] is selected]

- Press the Up/Down button to select the number of prints. Maximum 30 prints.
- Use the Left/Right button to select another picture and select the number of prints for another picture.
- After setting the number of prints, press the OK button to save.
- Press the Shutter button to return to the menu without setting the number of prints.

Downloaded From camera-usermanual.com Samsung Manuals

PictBridge: Printing

■ Printing Pictures

1. Connect the camera to your printer. The USB menu must be set to [PRINTER] before you connect the camera to the printer.(See p.63)
2. Use the LEFT and RIGHT buttons to select the [PRINT] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.
   [STANDARD] : Print the pictures stored in the memory card in set numbers. One picture is printed on one piece of paper.
   [INDEX] : Print multiple images on one sheet of paper.



4. The screen shown on the right will appear and the picture will be printed. If no picture is selected, the [NO IMAGE!] message will be displayed. Press the shutter button while printing to cancel the printing and the [IMAGES] menu is displayed.

※ Number of pictures in a index print varies depends on the printer used.

■ DPOF PRINT : This allows you to directly print the files with DPOF information.

1. Connect the camera to your printer. The [USB] menu must be set to [PRINTER] before you connect the camera to the printer.(See p.63)
2. Use the LEFT and RIGHT buttons to select the [DPOF PRINT] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.
   [NO] : Cancel the printing
   [YES]: Directly print the file with the DPOF information



※ Depending on the manufacturer and printer model, some menus may not be available. With a printer without supporting the DPOF, the menu is still displayed but not available.

Downloaded From camera-usermanual.com Samsung Manuals

PictBridge: Print Setting

■ AUTO SET

1. Connect the camera to your printer. The USB menu must be set to [PRINTER] before you connect the camera to the printer.(See p.63)
2. Use the LEFT and RIGHT buttons to select the [AUTO SET] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.

[NO] : [CUSTOM SET] values are kept.
[YES]: All values in the [CUSTOM SET] are automatically changed.

■ CUSTOM SET : You can select the Paper Size, Print Format, Paper Type, Print Quality, Date Print, and File Name Print menus for printed pictures.

1. Connect the camera to your printer. The [USB] menu must be set to [PRINTER] before you connect the camera to the printer.(See p.63)
2. Use the LEFT and RIGHT buttons to select the [CUSTOM SET] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the RIGHT button.
4. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.

● The menus you can set up are as follows:

Menu	Function	Sub menu
SIZE	Setting the size of the printing paper	AUTO, POSTCARD, 4X6, 2L, A4, LETTER, A3
LAYOUT	Setting the number of pictures to be printed on a sheet of paper	AUTO, INDEX, FULL, 1, 2, 4, 6, 8
TYPE	Setting the quality of the printing paper	AUTO, PLAIN, PHOTO, FASTPHO.
QUALITY	Setting the quality of the picture to be printed	AUTO, DRAFT, NORMAL, FINE
DATE	Setting whether to print the date	AUTO, OFF, ON
FILE NAME	Setting whether to print the file name	AUTO, OFF, ON

※ Some menu options are not supported in all manufacturer and printer models. If not supported, the menus are still displayed in the LCD, but are not selectable.
※ If the setting values are not changed in the automatic/manual setting, the setting values are automatically kept.

Downloaded From camera-usermanual.com Samsung Manuals

PictBridge : RESET

■ Initializes user-changed configurations.

1. Connect the camera to your printer. The [USB] menu must be set to [PRINTER] before you connect the camera to the printer.(See p.63)
2. Use the LEFT and RIGHT buttons to select the [RESET] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.

- If [NO] is selected : Settings will not be reset.
- If [YES] is selected : All print and image settings will be reset.

※ Default print setting varies depending on the printer manufacturer.
For your printer's default setting, refer to the user's guide that came with your printer.

Downloaded From camera-usermanual.com Samsung Manuals

Setup menu

- In this mode, you can set up basic settings.
  You can use the setup menu in all camera modes, except Voice Recording mode.
  The items indicated by [ ] are default settings.
- The OK button written in this manual means the MENU button.

Menu tab	Main menu	Sub menu	Secondary menu	Page
SET	FILE	RESET		p.69
		SERIES		
	PWR SAVE	OFF, 1, 3, 5, 7, 10MIN		p.70
	LANGUAGE	ENGLISH	PORTUGUÊS	p.71
		한국어	简体中文	
		FRANÇAIS	繁體中文	
		DEUTSCH	DANSK	
		ESPAÑOL	SVENSKA	
		ITALIANO	ไทย	
		РУССКИЙ	BAHASA	
		DUTCH	عربي	
	FORMAT	NO		p.72
		YES		
	DATE	05/03/01		p.73
	TIME	13:00		p.73
	DATE TYPE	YY/MM/DD		p.74
		DD/MM/YY		
		MM/DD/YY		
	IMPRINT	OFF		p.74
		DATE		
		D & TIME		
	BEEP	OFF		p.75
		ON		

Downloaded From camera-usermanual.com Samsung Manuals

Setup menu

Menu tab	Main menu	Sub menu	Secondary menu	Page
SET	USB	COMPUTER		p.75
		PRINTER		
	Q.VIEW	OFF, 0.5, 1, 3SEC		p.76
	RESET	NO		p.76
		YES		

* Menus are subject to change without prior notice.

File name

■ This function allows the user to select the file naming format.

● Assigning File Names



1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [FILE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   [RESET] : After using the reset function, the next file name will be set from 0001 even after formatting, deleting all or inserting a new memory card.
   [SERIES] : New files are named using numbers that follow the previous sequence, even when a new memory card is used, or after formatting, or after deleting all pictures
5. Press the menu button twice and the menu will disappear.

Downloaded From camera-usermanual.com Samsung Manuals

File name

INFORMATION

- The first stored folder name is 100SSCAM, and the first file name is S4020001.
- File names are assigned sequentially from S4020001 → S4020002 → ~ → S4029999.
- The folder number is assigned sequentially from 100 to 999 as follows: 100SSCAM → 101SSCAM → ~ → 999SSCAM.
- The files used with the memory card conform to the DCF(Design rule for Camera File systems) format.

Auto power off

■ This function switches the camera off after a set amount of time in order to prevent unnecessary battery drainage.

● Setting Power Off

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [PWR SAVE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   Selecting [OFF] : The power off function will not operate.
   [1, 3, 5, 7, 10 MIN] : The power will turn off automatically if not used for the period of time specified.
5. Press the menu button twice and the menu will disappear.

INFORMATION

- Even if the batteries are removed and inserted again, the power off setting will be preserved.
- Note that the automatic power off function will not operate if the camera is in PC mode, slide show, playing back a movie clip.

Downloaded From camera-usermanual.com Samsung Manuals

Language

■ There is a choice of languages that can be displayed on the LCD monitor. Even if the batteries are removed and inserted again, the language setting will be preserved.

● Setting Language

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [LANGUAGE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   LANGUAGE sub menu
   English, Korean, French, German, Spanish, Italian, S. Chinese, T. Chinese, Japanese, Russian, Portuguese, Dutch, Danish, Swedish, Finnish, Thai, BAHASA(MALAY/ INDONISIA) and Arabic.
5. Press the menu button twice and the menu will disappear.

Downloaded From camera-usermanual.com Samsung Manuals

Formatting a memory card

- This is used for formatting the memory card. If you run [FORMAT] on the memory card, all images, including the protected images, will be deleted. Be sure to download important images to your PC before formatting the memory card.
- If the memory card is not inserted, the internal memory will be formatted.

● Formatting a Memory Card

1. In any mode other than Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [FORMAT] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

If [NO] is selected : The memory card will not be formatted.
Press the menu button twice and the menu display will disappear.

If [YES] is selected : A confirmation window will display. Select the [FORMAT] menu by pressing the UP/DOWN button and press the OK button. A [PLEASE WAIT!] message appears and the memory card will be formatted. If you ran FORMAT in Play mode, a [NO IMAGE!] message will appear.

INFORMATION

- Be sure to run [FORMAT] on the following types of memory card.
  - A new memory card, or an unformatted memory card.
  - A memory card that has a file this camera can' t recognize or one that has been taken from another camera.
- Always format the memory card using this camera. If you insert a memory card that has been formatted using other cameras, memory card readers, or PCs, you will get a [CARD ERROR!] message.

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the Date

■ You can change the date that will be displayed on the captured images.

● Setting Date



1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [DATE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the UP, DOWN, LEFT, and RIGHT buttons to select the desired submenu value, and then press the OK button.

   RIGHT button : Selects the year / month / day.

   LEFT button : Moves the cursor to the [DATE] main menu if the cursor is at the first item of the date setup. In all other cases, the cursor will be shifted to the left of its current position.

   UP and DOWN buttons : Changes the setting value.
5. Press the menu button twice and the menu will disappear.

Setting up the Time

■ You can change the time that will be displayed on the captured images.

● Setting Time

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [TIME] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the UP, DOWN, LEFT, and RIGHT buttons to select the desired submenu value, and then press the OK button.

   RIGHT button : Selects the hour/ minute.

   LEFT button : Moves the cursor to the [TIME] main menu if the cursor is at the first item of the time setup. In all other cases, the cursor will be shifted to the left of its current position.

   UP and DOWN buttons : Changes the setting value.
5. Press the menu button twice and the menu will disappear.

Downloaded From camera-usermanual.com Samsung Manuals

Date type

■ You can change the date type that will be displayed on the captured images.

● Setting up the Date type

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [DATE TYPE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   - Date type : [YY/MM/DD] / [MM/DD/YY] / [DD/MM/YY]
5. Press the menu button twice and the menu will disappear.

Imprinting the recording date

■ There is an option to include DATE/ TIME on still images.

● Date Imprinting

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [IMPRINT] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the UP and DOWN buttons to select the desired date imprint type, and then press the OK button.
   [OFF] : The DATE & TIME will not be imprinted on the image file.
   [DATE] : Only the DATE will be imprinted on the image file.
   [D&TIME] : The DATE & TIME will be imprinted on the image file.
5. Press the menu button twice and the menu will disappear.



INFORMATION

- The Date & Time are imprinted at the bottom right side of the still image.
- The date will be imprinted as a DATE TYPE setting.
- TIME is imprinted in the following way : [Hour : Minute : Second] and hours are shown using the 24 hour clock.
- The imprint function is applied only to still images.

Downloaded From camera-usermanual.com Samsung Manuals

Beep

■ If you set the operation sound to ON, various sounds will be activated for camera startup, when button are pressed, and if there is a card error, so that you can be aware of the camera operation status.

● Setting Operation Sounds



1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [BEEP] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   [BEEP] sub menu : OFF/ON
5. Press the menu button twice and the menu will disappear.

Selecting an External Device (USB)

■ You can select an external device to which you want to connect the camera using the USB cable.

● Selecting an External Device



1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [USB] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   [COMPUTER] : Select this if you want to connect the camera to your PC.
   Refer to page 95 for instructions on how to connect the camera to your PC.
   [PRINTER] : Select this if you want to connect the camera to your printer.
   Refer to page 63 for instructions on how to connect the camera to your printer.
5. Press the menu button twice and the menu will disappear.

Downloaded From camera-usermanual.com Samsung Manuals

Quick view

■ If you enable Quick View before capturing an image, you can view the image you just captured on the LCD monitor for the duration set in the [Q.VIEW] setup. Quick view is possible only with still images.

● Setting Quick View



1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [Q.VIEW] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   [OFF] : The quick view function can't be activated.
   [0.5, 1, 3 SEC] : The captured image is briefly displayed during the selected time.
5. Press the menu button twice and the menu will disappear.

Initialization(RESET ALL)

■ All camera menu and function settings will be restored to their default values. However, values for DATE/TIME and LANGUAGE will not be changed.

● Initializing the Camera

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [RESET] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
   If [NO] is selected : Settings will not be restored to their defaults.
   If [YES] is selected : All settings will be restored to their defaults.
5. Press the menu button twice and the menu will disappear.

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the MYCAM menu

■ You can set up a start up image and start up sound. Every camera working mode (with the exception of Voice recording mode) has the MyCAM menu.
The items indicated by [ ] are default settings.

Menu tab	Main menu	Sub menu		Page
	S.IMAGE	OFF	IMAGE 1	p.77
		IMAGE 2	USER IMAGE	
	S.BEEP	OFF	ON	p.78

* Menus are subject to change without prior notice.

Start up image

■ You can select the image that is first displayed on the LCD monitor whenever the camera is turned on.

● Setting a Startup Image

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [MYCAM] menu tab.
3. Select the [S.IMAGE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
5. Press the menu button twice and the menu will disappear.



INFORMATION

● Use a saved image for the start-up image with the [LOGO] in the [RESIZE] menu in the play mode.
● The start-up image will not be deleted by deleting all images or [FORMAT] menu.

Downloaded From camera-usermanual.com Samsung Manuals

Start up sound

■ You can select the sound that is activated whenever the camera is turned on.

● Setting the Startup Sound



1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [MYCAM] menu tab.
3. Select the [S.BEEP] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

   If [OFF] is selected : Start up sound will not be activated whenever the camera is turned on.

   If [ON] is selected : Start up sound will be activated whenever the camera is turned on.
5. Press the menu button twice and the menu will disappear.

Downloaded From camera-usermanual.com Samsung Manuals

Important notes

Be sure to observe the following precautions!

■ This unit contains precision electronic components. Do not use or store this unit in the following locations.
- Areas exposed to severe changes in temperature and humidity.
- Areas exposed to dust and dirt.
- Areas exposed to direct sunlight or the inside of a vehicle in hot weather.
- Environments where there is high magnetism or excessive vibration.
- Areas with high explosives or highly flammable materials.

■ Do not leave this camera in places subject to dust, chemicals (like naphthalene and mothball), high temperature and high humidity.
Keep this camera with silica gel in a hermetically sealed box when not planning to use the camera for a long period of time

■ Sand can be particularly troublesome to cameras.
- Do not let sand get inside the unit when using it on beaches, coastal dunes, or other areas where there is lots of sand.
- Doing so may result in failure or may permanently render the unit unusable.

■ Handling the camera
- Never drop the camera or subject it to severe shocks or vibrations.
- This camera is not waterproof.
  To avoid dangerous electrical shocks, never hold or operate the camera with wet hands.
- If you use this camera in wet places, such as beach or pool, do not let water or sand get inside the camera. Doing so may result in failure or may permanently damage the unit.

■ Extremes in temperature may cause problems.
- If the camera is transferred from a cold to a warm and humid environment, condensation can form on the delicate electronic circuitry. If this occurs, turn the camera off and wait for at least 1 hour until all moisture is dispersed. Moisture build up can also occur in the memory card. If this happens, turn off the camera and remove the memory card. Wait until the moisture has dispersed.

Downloaded From camera-usermanual.com Samsung Manuals

Important notes

■ Caution on Using the Lens
- If the lens is subjected to direct sunlight, it could result in discoloration and deterioration of the image sensor.
- Pay attention not to get fingerprints or foreign substances on the surface of the lens.

■ If the digital camera is not used for a long period, an electric discharge can occur. It is a good idea to remove the batteries and the memory card if you do not intend using the camera for an extended period of time.

■ If the camera is exposed to an electronic interference, it will turn itself off to protect the memory card.

■ Camera Maintenance
- Use a soft brush (available from photo stores) to gently clean the lens and LCD assemblies. If this does not work, lens-cleaning paper with lens cleaning fluid can be used. Clean the camera body with a soft cloth. Do not allow this camera to come into contact with solvent materials such as benzol, insecticide, thinners etc. This may damage the body shell of the camera and also affect its performance. Rough handling can damage the LCD monitor. Take care to avoid damage and keep the camera in its protective carry case at all times when not in use.

■ Do not attempt to disassemble or modify the camera.

■ Under certain conditions, static electricity can cause the flash unit to fire. This is not harmful to the camera and is not a malfunction.

■ When images are uploaded or downloaded, the data transfer may be affected by static electricity. In this case, disconnect and re-connect the USB cable before trying the transfer again.

■ Before an important event or going on a trip, you should check the camera condition.
- Take a picture for testing the camera condition and prepare extra batteries.
- Samsung cannot be held responsible for camera malfunctions.

Downloaded From camera-usermanual.com Samsung Manuals

Warning indicator

■ There are several warnings that may appear on the LCD display

CARD ERROR !

· Memory card error
  → Turn off the camera power and turn it on again
  → Insert the memory card again
  → Insert the memory card and format the memory card (p.72)

MEMORY ERROR!

· Internal memory error
  → Turn off the camera power and turn it on again
  → Format the memory with the memory card removed. (p.72)

NO CARD !

· A memory card is not inserted
  → Insert a memory card
· The camera can't recognize the memory card
  → Insert the memory card again
  → Turn off the camera power and turn it on again

CARD LOCKED !

· The memory card is locked
  → SD memory card : Slide the write protect switch to the top of the memory card

CARD FULL !

· There is insufficient memory capacity to take an image
  → Insert a new memory card
  → Delete unnecessary image files to free up some memory

NO IMAGE !

· There are no images stored on the memory card
  → Take images
  → Insert a memory card that is holding some images

FILE ERROR !

· File error
  → Format the memory card
· Memory card error
  → Contact a camera service centre

Downloaded From camera-usermanual.com Samsung Manuals

Warning indicator

LOW BATTERY !

· There is low battery capacity
→ Insert fresh batteries

LOW LIGHT !

· When taking pictures in dark places
→ Use a tripod and take pictures in Flash Photography mode

SET USB

· [USB] sub menu and connected device are not matched.
→ Reconfigure [USB] in the [SETUP] menu.

OUT OF NUMBER

· When selecting too many printing pages in the PictBridge menu.
→ Select printing page within the limitation.

Before contacting a service centre

■ Please check the following

The camera doesn't switch on

· There is low battery capacity
→ Insert fresh batteries
· Batteries are inserted incorrectly with the reverse polarities
→ Insert the batteries according to the polarity marks (+, -)

The camera power ceases whilst in use

· The batteries are exhausted
→ Insert fresh batteries
· The Camera is turned off automatically
→ Turn off the camera power and turn it on again

Batteries drain quickly

· The Camera is being used in low temperatures
→ Keep the camera in warm conditions (i.e. inside a coat or jacket) and only remove it in order to take images

Downloaded From camera-usermanual.com Samsung Manuals

Before contacting a service centre

Camera does not take images when pressing the Shutter button

- There is insufficient memory capacity
  → Delete unnecessary image files
- The memory card has not been formatted
  → Format the memory card (p.72)
- The memory card is exhausted
  → Insert a new memory card
- The memory card is locked
  → Refer to [CARD LOCKED!] error message (p.81)
- The camera's power is off
  → Turn the camera power on
- The batteries are exhausted
  → Insert fresh batteries
- Batteries are inserted incorrectly with the reverse polarities
  → Insert the batteries according to the polarity marks (+, -)

The camera suddenly stops working while in use

- The camera was stopped due to a malfunction
  → Remove /re-insert batteries and switch the camera on

The images are unclear

- An Incorrect focus mode is selected.
  → Select a correct focus mode related to the distance.
- Taking a picture beyond the flash range
  → Take a picture within the flash range
- The lens is smudged or dirty
  → Clean the lens

The flash does not fire

- Flash off mode has been selected
  → Dis-engage flash off mode
- The camera mode can't use the flash
  → Refer to the FLASH instruction (p.26)

Incorrect date and time is displayed

- The date and time have been set incorrectly or the camera has adopted the default settings
  → Reset the date and time correctly

Downloaded From camera-usermanual.com Samsung Manuals

Before contacting a service centre

The images don't play back

· Incorrect file name (Violation of DCF format)

→ Do not change the image file name

Colour of image is different to the original scene

· White balance setting is incorrect

→ Select appropriate White balance

Images are too bright

· Exposure is excessive

→ Reset exposure compensation

When using the PC's explorer, the [Removable Disk] file does not show

· Cable connection is incorrect

→ Check the connection

· The camera is off

→ Turn the camera on

· The operating system is not Windows 98, 98SE, 2000, ME, XP/ Mac OS 9.2~10.3. Alternatively the PC does not support USB

→ Install Windows 98, 98SE, 2000, ME, XP/ Mac OS 9.2~10.3 to PC that supports USB

· The camera driver is not installed

→ Install a [USB Storage Driver]

Downloaded From camera-usermanual.com Samsung Manuals

Specifications

Image Sensor	Type	1/2.5" CCD
	Effective Pixels	Approx. 4.0 Mega-pixel
	Total Pixels	Approx. 4.2 Mega-pixel
Lens	Focal Length	Lens f=5.8mm (35mm film equivalent:35mm)
	F No.	F 3.5 / F7.0
	Digital Zoom	Still Image mode: 1.0X ~ 4.0X Play mode: 1.0X ~ 7.0X (depends on Image size)
LCD		1.8" color TFT LCD
Focusing	Type	Fixed focus with two steps manual adjustment
	Range	Macro: 0.2m Normal: 1.0m~infinity
Shutter	Type	Mechanical and Electronic shutter
	Speed	2 - 1/1000 sec.(8 – 1/1000sec.in Night Mode)
Exposure	Control	Programmed AE Metering: Multi, Spot
	Compensation	±2.0EV (0.5EV steps)
	ISO Equivalent	Auto,100,200,400
Flash	Modes	Auto, Auto & Red - eye reduction, Fill-in flash, Slow sync, Flash Off
	Range	0.2m ~ 2.5m
	Recharging Time	Approx. 5 sec.
Sharpness		Soft, Normal, Vivid
Effect		Normal, B&W, Sepia
White Balance		Auto, Daylight, Cloudy, Sunset, Fluorescent(H), Fluorescent(L), Tungsten, Custom
Photo Frame		9 Frames
Voice Recording		Voice Recording (max. 1 hour) Voice Memo on Still Image (max. 10.sec)
Date Imprinting		Off, Date, Date & Time (User selectable)
Shooting	Still Image	Mode: Auto, Program, Scene Scene : Night, Portrait, Landscape, Fireworks Shooting: Single, continuous
	Movie Clip	With audio (recording time: memory capacity dependent) Size: 640 x 480, 320 x 240 Frame rate: 24, 15fps
Self-timer		2sec, 10 sec, Double self (10/2sec.)
Storage	Media	Internal memory: 16MB flash memory External memory: SD card /MMC (Up to 512MB Guaranteed)
	File Format	Still Image: JPEG (DCF), EXIF 2.2, DPOF 1.1, PictBridge 1.0 Movie Clip: AVI (MJPEG) Audio: WAV

Downloaded From camera-usermanual.com Samsung Manuals

Specifications

Storage	Image Size	2272 : 2272X1704 2048 : 2048X1536 1600 : 1600X1200 1024 : 1024X768 640 : 640X480
	Capacity (16MB)	2272 : Super fine (10) Fine (20) Normal (33) 2048 : Super fine (13) Fine (27) Normal (42) 1600 : Super fine (17) Fine (37) Normal (50) 1024 : Super fine (38) Fine (78) Normal (113) 640 : Super fine (81) Fine (145) Normal (234) * These figures are measured under Samsung's standard conditions and may vary depending on shooting conditions and camera settings.
Image Play	Type	Single image / Thumbnails / Slide show/ Movie clip
	Editing	Rotation, Trimming, Resizing
Interface		Digital output connector: USB 1.1
Power Source		Primary battery : 2 x AA alkaline, Lithium, Ni-Mn, Ni-Zn, 1X CR-V3 Rechargeable battery : 2 x AA Ni-MH, Ni-Cd / 1 x I-Pack (SBP-1303)
Dimensions (WxHxD)		96.5 x 52.5 x 30.5 mm
Weight		Approx. 90g (without batteries and card)
Operating Temperature		0 ~40 ˚C
Operating Humidity		5 ~85%
Software	Camera Driver	Storage Driver (Windows98/98SE)
	Application	Digimax Viewer, Arcsoft PhotoImpression

* Specifications are subject to change without prior notice.
* All trademarks are the property of their respective owners.

Downloaded From camera-usermanual.com Samsung Manuals

Software Notes

Please ensure that you read the instruction manual carefully before use.

- The attached software is a camera driver and image editing software tool for Windows.
- Under no circumstances should all or part of either the software or the user manual be reproduced.
- Copyrights for software are licensed only for use with a camera.
- In the unlikely event of a manufacturing fault, we will repair or exchange your camera. We cannot, however, be held responsible in any way for damage caused by inappropriate use.
- Using a Hand-made PC or a PC and OS that has not been guaranteed by the manufacturer is not covered by the Samsung warranty.
- Before reading this manual, you should have a basic knowledge of computers and O/S (Operating Systems).

System Requirements

For Windows	For Macintosh
PC with processor better than MMX Pentium 233MHz (XP : Pentium II 300MHz)	Power Mac G3 or later
Windows 98/98SE/2000/ME/XP	Mac OS 9.2~10.3
Minimum 32MB RAM (XP : 128MB) 140MB of available hard-disk space	Minimum 64MB RAM 110MB of available hard-disk space
USB port	USB port
CD-ROM drive	CD-ROM drive
800x600 pixels, 16-bit colour display compatible monitor (24-bit colour display recommended)	QuickTime 6.01 or later for Movie Clip

Downloaded From camera-usermanual.com Samsung Manuals

About the software

After inserting the CD-ROM provided with this camera into the CD-ROM drive, the following window should automatically run.


SAMSUNG
Digimax A402
KENOX D402
Installer
Thank you for purchasing Samsung Digital Camera.
It is strongly recommended that you exit all Windows programs before installing this program.
If the camera is connected to your computer through USB cable, please remove the cable and then click [Install].
After installing the Digimax A402 / KENOX D402 Driver, you can install Digimax Viewer 2.1 and ArcSoft PhotoImpression 4.
Install
Exit
www.samsungcamera.com
www.samsungcamera.co.kr
Browse CD

Before connecting the camera to the PC, you should first install the camera driver.

■ Camera driver : This enables images to transfer between the camera and PC.
This camera uses the USB Storage Driver as the camera driver. You can use the camera as a USB card reader. After installing the driver and connecting this camera to the PC, you can find [Removable Disk] in [Windows Explorer] or [My computer]. A USB Storage Driver is provided only for Windows. A USB Driver for MAC is not included with the Application CD. But you can use the camera with Mac OS 9.2~10.3.

■ Digimax Viewer : This is a program for viewing stored images.
You can see the stored images in the memory directly on a PC monitor. You can also copy, move or delete the images and enlarge/downscale the image sizes with Digimax Viewer. This software is only compatible with Windows.

■ PhotoImpression : Image editing program.
You can edit or store still images that you download from the camera. This software is only compatible with Windows.

INFORMATION

- Be sure to check the system requirements (p.87) before installing the driver.
- You should allow 5 ~ 10 seconds for running the automatic setup program according to the capability of the computer. If the frame does not show, run the [Windows Explorer] and select [Samsung.exe] in the CD-ROM Drive root directory.

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the application software

To use this camera with a PC, install the application software first. After this has been done, the stored images in the camera can be moved to the PC and can be edited by an image editing program.

INFORMATION

- Close other programs before installing the application software.
- Before installing the application software, disconnect the USB connection.

You can visit the Samsung web-site through the internet.

http://www.samsungcamera.com : English
http://www.samsungcamera.co.kr : Korean

1. Click the [Install] menu in the Autorun frame.
   The camera driver is installed automatically.

[Click!]


Digimax A402
KENOX D402
Installer
Thank you for purchasing Samsung Digital Camera.
It is strongly recommended that you exit all Windows programs before installing this program.
If the camera is connected to your computer through USB cable, please remove the cable and then click [Install].
After installing the Digimax A402 / KENOX D402 Driver,
PhotoImpression 4.
Install
Exit
www.samsungcamera.com
www.samsungcamera.co.kr
Browse CD

2. Camera driver installation is complete.
   Click the [Finish] button.

[Click!]



Downloaded From camera-usermanual.com Samsung Manuals

Setting up the application software

3. A window for which you can select application software will be displayed. Select the application program and click the [Install] button. Refer to page 88 for more information about the application program.

[Click!]



INFORMATION

- If you select [Exit] at the step 3, the application program installation will be cancelled.

4. Install Digimax Viewer.
Click [Next >] button.

[Click!]

InstallShield Wizard
Welcome to the InstallShield Wizard for Digimax Viewer 2.1
The InstallShield® Wizard will install Digimax Viewer 2.1 on your computer. To continue, click Next.
Next >
Cancel

INFORMATION

- If you select [Cancel] at step 4, a window for installing PhotoImpression will be displayed.

5. The Software License Agreement window will be displayed. If you agree to this, click [Yes], the window will then move to the next step. If you disagree, click [No] and the installation program will be cancelled.

[Click!]


InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
Press the PAGE DOWN key to see the rest of the agreement.
END USER LICENSE AGREEMENT
SOFTWARE LICENSE
Do you accept all the terms of the preceding License Agreement? If you choose No, the setup will close. To install Digimax Viewer 2.1, you must accept this agreement.
Yes
No

6. A destination selection window will open. Click [Next >]. To copy to the files to another folder, click [Browse...] and choose a folder you want.

[Click!]


InstallShield Wizard
Choose Destination Location
Select folder where Setup will install files.
Setup will install Digimax Viewer 2.1 in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
C:\Program Files\Samsung\Digimax Viewer 2.1
Browse...
Next >
Cancel

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the application software

7. A window will open, asking you to choose a folder to which program icons will be added. Click [Next >] button. If you want to add the program icons to a different folder, choose another folder, and then click [Next >] button.


InstallShield Wizard
Select Program Folder
Please select a program folder.
Setup will add program icons to the Program Folder listed below. You may type a new folder name, or select one from the existing folders list. Click Next to continue.
Program Folders:
Digimax Viewer 2.1
Existing Folders:
Accessories
Administrative Tools
Microsoft Global IME
Online Services
StartUp
InstallShield
Next >
Cancel

[Click!]

8. Digimax Viewer installation is successfully completed. Click the [Finish] button to install PhotoImpression. The system will not reboot even if the [Yes, I want to restart the computer now] option is selected.
   * The frame 8 may not appear according to the system requirements.


InstallShield Wizard
InstallShield Wizard Complete
The InstallShield Wizard has successfully installed Digimax Viewer 2.1. Before you can use the program, you must restart your computer.
Yes, I want to restart my computer now.
No, I will restart my computer later.
Remove any disks from their drives, and then click Finish to complete setup.
< Back
Finish
Cancel

[Click!]

9. The PhotoImpression installation window will be displayed as shown alongside.
   Click the [OK] button.

[Click!]

10. A Welcome window will be displayed.
    Click the [Next >] button.


ArcSoft PhotoImpression 4 Setup
ArcSoft
Welcome to the InstallShield Wizard for PhotoImpression
The InstallShield® Wizard will install PhotoImpression on your computer. To continue, click Next.
< Back
Next >
Cancel

[Click!]

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the application software

11. The Software License Agreement window will be displayed. If you agree to this, click [Yes], the window will then move to the next step. If you disagree, click [No] and the installation program will be cancelled.

ArcSoft PhotoImpression 4 Setup
License Agreement
Please read the following license agreement carefully.
ArcSoft
Press the PAGE DOWN key to see the rest of the agreement.
End User License Agreement
Grant of License. This license permits you to use one copy of the software included in this package on any single computer. For each software licenses, the program can be "in use" on only one computer at any given time. The software is "in use" when it is either
Do you accept all the terms of the preceding License Agreement? If you choose No, the setup will close. To install PhotoImpression, you must accept this agreement.
InstallShield
< Back
Yes
No

[Click!]

12. A destination selection window will open. Click [Next >]. To copy to the files to another folder, click [Browse...] and choose a folder you want.


ArcSoft PhotoImpression 4 Setup
Choose Destination Location
Select folder where Setup will install files.
ArcSoft
Setup will install PhotoImpression in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
C:\Program Files\ArcSoft\PhotoImpression 4
Browse...
InstallShield
< Back
Next >
Cancel

[Click!]

13. The [Select Components] window will appear. Click [Next >] button.



[Click!]

14. A window will open, asking you to choose a folder to which program icons will be added. Click [Next >] button. If you want to add the program icons to a different folder, choose another folder, and then click [Next >] button.



[Click!]

Downloaded From camera-usermanual.com Samsung Manuals

Setting up the application software

15. Installation is complete. To apply changes, you must restart the computer.
Select [Yes, I want to restart my computer now], and then click [OK].


SAMSUNG
Digimax A402
KENOX D402
Installer
Setup is complete.
Before you can use the program, you must restart your computer.
Yes, I want to restart my computer now.
No, I will restart my computer later.
OK

[Click!]

* The frame 15 may be displayed according to the system requirements.
Click the [Finish] button to restart the computer.


InstallShield Wizard
InstallShield Wizard Complete
Yes, I want to restart my computer now.
No, I will restart my computer later.
Remove any disks from their drives, and then click Finish to complete setup.
Finish
Cancel

[Click!]

16. After restarting the computer, connect the PC to the camera with the USB cable.

17. Turn the camera power on. [Found New Hardware Wizard] will open and the computer will recognise the camera.
* If you have ever installed an image viewer program or your OS is Windows XP, an image viewer program will open. If the image viewer program opens, the camera driver was setup successfully.



18. If you can see [Removable Disk] under [My computer], the camera driver installation was successful. Now you can transfer image files from the camera to PC via the USB cable.



Downloaded From camera-usermanual.com Samsung Manuals

Setting up the application software

INFORMATION

- If you have installed the camera driver, [Found New Hardware Wizard] may not open.
- On a Windows 98 or 98 SE system, the Found New Hardware Wizard dialog box opens and a window asking you to select a driver file may appear. In this case, specify "USB Driver" in the CD supplied.
- Before connecting the camera to the PC, You should first install the camera driver.
- After installing the camera driver, you have to restart your PC.
- If you connect the camera to the PC before installing the camera driver, the [Found New Hardware Wizard] will open.
  In this case, cancel the [Found New Hardware Wizard] and disconnect the camera. Install the camera driver (p.89) and connect the camera to the PC again.
- Should the computer not find the camera driver after installation, please try one or more of the following measures.
  1. Delete the camera driver (p.98), and re-install the driver.
  2. Refer to FAQ (p.104) to check for a possible solution to the problem.
  3. If your PC's central processing unit is VIA chip (This is shown in the USB Host Controller), download the patch file from the Samsung Camera web page. (http://www.samsungcamera.com)

Downloaded From camera-usermanual.com Samsung Manuals

Starting PC mode

- If you connect the USB cable to a USB port on your PC and then turn on the power, the camera will automatically switch to "computer connection mode".
- In this mode, you can download stored images to your PC through the USB cable.
- The LCD monitor is always turned off in PC mode.
- The camera status lamp will blink when the files are transferring via the USB connection.

■ Connecting the camera to a PC



1. Turn the PC power on.
2. Turn the camera power on.
3. In any mode other than Voice Recording mode, press the MENU button.
4. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
5. Select the [USB] menu by pressing the UP/ DOWN button and press the RIGHT button.
6. Use the UP and DOWN buttons to select [COMPUTER], and then press the OK button.
7. Press the menu button twice and the menu will disappear.
8. Connect the PC and the camera via the USB cable.
   - Insert the small plug of the USB cable into the camera USB connection terminal.
   - Insert the large connector of the USB cable into the USB port of the PC.
   - The plugs must be firmly inserted.

※ If you selected [PRINTER] in Step 6, when you connect the camera to your printer, the [CONNECTING…] message will be displayed on the LCD monitor and the connection will not be established. In this case, disconnect the USB cable, and then follow the procedure from Step 3 and onward.



■ Disconnecting the camera and PC : Refer to page 98(Removing the removable disk).

INFORMATION

● The camera driver must be installed before using PC mode.

Downloaded From camera-usermanual.com Samsung Manuals

Starting PC Mode

■ Downloading stored images

You can download the still images stored on the camera to your PC's hard disk and print them or use a photo editing software to edit them.

1. Connect the camera to your PC with the USB cable.

2. On your computer's desktop display, select [My computer] and double click [Removable Disk → DCIM → 100SSCAM].
The image files will then be displayed.



3. Select an image and press the right mouse button.



4. A pop-up menu will open.
Click [Cut] or [Copy] menu.
- [Cut] : cuts a selected file.
- [Copy] : copies files.



5. Click a folder where you want to paste the file.

Downloaded From camera-usermanual.com Samsung Manuals

6. Press the right mouse button and a pop-up menu will open. Click [Paste].



7. An image file is transferred from the camera to your PC.



- By using [Digimax Viewer], you can see the stored images in the memory directly on the PC monitor and you can copy or move the image files.

Downloaded From camera-usermanual.com Samsung Manuals

Removing the USB Driver for Windows 98SE

■ To remove the USB driver, refer to the process shown below.

1. Trace [Start → Settings] and click [Control Panel].



2. Double-click [Add/Remove programs].

3. The [Add/Remove Programs Properties] window will open. Click [Digimax A402] and click the [Add/Remove] button.


Add/Remove Programs Properties
Install/Uninstall
Windows Setup
Startup Disk
To install a new program from a floppy disk or CD-ROM drive, click Install.
Install...
The following software can be automatically removed by Windows. To remove a program or to modify its installed components, select it from the list and click Add/Remove.
Digimax A402
LiveReg (Symantec Corporation)
LiveUpdate 1.80 (Symantec Corporation)
Norton Ghost
NVIDIA Windows 95/98/ME Display Drivers
Add/Remove...
OK
Cancel
Apply

[Click!]

4. Uninstallation is complete.
Click the [Finish] button and the window will disappear.

[Click!]

Downloaded From camera-usermanual.com Samsung Manuals

Removable Disk

■ To use this camera as a Removable Disk, install (p.89) the USB Driver.

1. Before turning the camera power on, connect the camera to the PC with the USB cable.

2. Click [Removable Disk] under [My computer] or [Windows Explorer].

3. Image files stored in the Removable Disk (DCIM → 100SSCAM) can be transferred to the PC.

INFORMATION

Important information whilst using the Removable Disk

- The [Removable Disk] indicator will not show when the camera power is off or the USB cable is removed.
- We recommend that you should copy the images to the PC to view them. Opening images directly from the removable disk may be subject to unexpected disconnection.
- When uploading images from the PC to the camera, ensure that the uploaded file names are not the same as those already stored on the memory.
- When you upload a file that is not taken by this camera to Removable Disk, the [FILE ERROR!] message will be displayed on the LCD monitor in the PLAY mode, and nothing is displayed in THUMBNAIL mode.
- The camera status lamp will blink, when a file is transferred (copy or deletion) between the PC and the camera. Do not remove the USB cable until the lamp stops blinking.
  To remove the USB cable in Windows 2000/ME/XP, use the [Unplug or Eject Hardware] icon on the task bar.



Downloaded From camera-usermanual.com Samsung Manuals

Removing the removable disk

■ Windows 98SE

1. Check whether the camera and PC are transferring a file. If the camera status lamp blinks, you have to wait until the lamp illuminates.
2. Unplug the USB cable.

■ Windows 2000/ME/XP

(The illustrations may be different from the real display in accordance with the Windows O/S.)

1. Check whether the camera and PC are transferring a file. If the camera status lamp blinks, you have to wait until the lamp illuminates.

2. Double-click the [Unplug or Eject Hardware] icon on the task bar.

3. The [Unplug or Eject Hardware] window will open. Select the [USB Mass Storage Device] and click the [Stop] button.

Unplug or Eject Hardware
Select the device you want to unplug or eject, and then click Stop. When Windows notifies you that it is safe to do so unplug the device from your computer.
Hardware devices:
USB Mass Storage Device
[Click!]
USB Mass Storage Device at Samsung Digital Camera
Properties
Stop
Display device components
Show Unplug/Eject icon on the taskbar
Close

4. The [Stop a Hardware device] window will open. Select the [USB Mass Storage Device] and click the [OK] button.


Stop a Hardware device
Confirm devices to be stopped, Choose OK to continue.
Windows will attempt to stop the following devices. After the devices are stopped they may be removed safely.
USB Mass Storage Device
Generic volume - (F:)
Samsung Digital Camera
[Click!]
OK
Cancel

5. A [Safe to Remove Hardware] window will open. Click the [OK] button.

Downloaded From camera-usermanual.com Samsung Manuals

Removing the removable disk

6. A [Unplug or Eject Hardware] window will open. Click the [Close] button and the removable disk will be removed safely.

Unplug or Eject Hardware
Select the device you want to unplug or eject, and then click Stop. When Windows notifies you that it is safe to do so unplug the device from your computer.
Hardware devices:
Properties
Stop
Display device components
Show Unplug/Eject icon on the taskbar
Close
[Click!]

7. Unplug the USB cable.

Setting up the USB Driver for MAC

1. A USB Driver for MAC is not included with the software CD as MAC OS supports the camera driver.
2. Check the MAC OS. You can check the MAC OS version during MAC OS start-up. This camera is compatible with MAC OS 9.2~10.3.
3. Connect the camera to the Macintosh and turn the camera power on.
4. A new icon will be displayed on the desktop after connecting the camera to the MAC.

Using the USB Driver for MAC

1. Double click a new icon on the desktop and the folder in the memory will be displayed.
2. Select an image file and copy or move it to MAC.

INFORMATION

- For Mac OS 10.0 or later : First complete uploading from computer to camera and then remove the removable disk with the Extract command

Downloaded From camera-usermanual.com Samsung Manuals

Digimax Viewer 2.1

■ This software is only compatible with Windows.

1. To open Digimax Viewer, click the [Start → Programs → Samsung → Digimax Viewer 2.1 → Digimax Viewer 2.1] and Digimax Viewer 2.1 will then open.

2. If the [Auto Launch] option is selected, this program will be executed automatically by recognising the camera.

3. You can easily use the Digimax viewer 2.1 program as it offers a FILE menu and TOOL bar.And, you can use the pop up menu. Click an image and press the right mouse button.

Digimax Viewer functions are listed below.

- Basic functions : Copy, Move, Delete, Rotate, Rename, changing file type, Resize, Property.
- Advanced functions : Print, Slide show, Export, Sending e-mail, On-line print, Web album etc.

INFORMATION

- Before deleting images from the camera, you should protect or download images to your computer that you wish to keep.
- Refer to the [Help] menu in Digimax viewer 2.1 for further information.

Downloaded From camera-usermanual.com Samsung Manuals

Using PhotoImpression

With PhotoImpression, you can edit or store still images that you downloaded from the camera. This software is only available in Windows version.

To start the program, click [Start → Programs → ArcSoft PhotoImpression → PhotoImpression]. The following screen will appear.

[Help Button]

[Command Button]

[Tool Bar]

You can use PhotoImpression to perform the following tasks.

■ Command Button

Button	Description
	Imports a picture from an album, a source folder, or the camera/scanner, or captures screen shots of what is being viewed on the current monitor.
	Selects Cut, Resize, Edit Image, Insert Text, Enhance Picture, Insert Effects, or Layer.
	Performs Insert Frame, Insert Borders, Insert Calendar, Insert Greeting Cards, Insert Template, or Connect with Other Software.
	Saves the edited picture, and sends an e-mail or uses it as the background image.
	Outputs the edited picture according to your preferences.

Downloaded From camera-usermanual.com Samsung Manuals

Using PhotoImpression

■ Tool Bar

Button	Description	Button	Description
	Resize Layer		Rotate Layer
	Flip Layer Horizontally		Rotate All Layers
	Undo		Redo
	Copy		Paste
	Delete Layer		Close Picture

INFORMATION

● For detailed instructions on how to use PhotoImpression, please refer to the program's Help.

FAQ

■ Please check the following if the USB connection malfunctions.

[Case 1] The camera power is off.
→ Turn the camera power on. We recommend using an AC power adapter in PC mode.

[Case 2] USB Driver is not installed correctly.
→ Install the USB Driver correctly. Refer to page 89.

[Case 3] The USB cable is not connected or you are using a cable with an incorrect specification.
→ Use a USB cable with the correct specification.

Downloaded From camera-usermanual.com Samsung Manuals

[Case 4] The camera is not recognised by your PC.
Sometimes, the camera may appear under [Unknown Devices] in Device Manager.
→ Install the camera driver correctly.
Turn off the camera, remove the USB cable, plug in the USB cable again, and then turn on the camera.

[Case 5] There is an unexpected error during file transfer
→ Turn the camera power off and on again. Transfer the file again.

[Case 6] How do I know my computer supports a USB Interface?
→ Check the USB port in your computer or keyboard.
→ Check the OS version. A USB Interface is available in Windows 98, 98SE, 2000, ME .XP.
→ Check [Universal Serial Bus controllers] in Device Manager. Do the following to check [Universal Serial Bus controllers].
Win 98/ME : Trace [Start → Settings → Control Panel → System → Device Manager → Universal Serial Bus controllers].
Win 2000 : Trace [Start → Settings → Control Panel → System → Hardware → Device Manager → Universal Serial Bus controllers].
Win XP : Trace [Start → Control Panel → System → Hardware → Device Manager → Universal Serial Bus controllers].
There must be USB Host Controller and USB root hub under [Universal Serial Bus controllers].
In addition, double-click on the USB Universal Host Controller and the USB Root Hub to check if the Device Status states "This device is working properly". If the Device Status says the device is "not working properly", click the "Driver" tab and then click [Update Driver] or [Reinstall Driver].
→ When all the conditions mentioned above are met, the computer can support the USB interface.

[Case 7] When using the USB hub.
→ There may be a problem in connecting the camera to the PC through the USB hub if the PC and the hub are not compatible.
Wherever possible, connect the camera to the PC directly.

[Case 8] Are other USB cables connected to the PC?
→ The camera may malfunction when it is connected to the PC at the same time as another USB cable. In this case, disconnect the other USB cable, and connect only one USB cable to the camera.

Downloaded From camera-usermanual.com Samsung Manuals

[Case 9] When I open the Device Manager (by clicking Start → (Settings) → Control Panel → (Performance and Maintenance) → System → (Hardware) → Device Manager), there are 「 Unknown Devices 」 or 「 Other Devices 」 entries with a yellow question mark(?) beside them or devices with an exclamation mark(!) beside them.

→ Right-click on the entry with the question(?) or exclamation (!) mark and select "Remove". Restart the PC and connect the camera the again.
For Windows 98 PC, remove the camera driver also, restart the PC, and then reinstall the camera driver.

→ Double-click on the entry with the question (?) or exclamation (!) mark, click the "Driver" tab, and click [Update Driver] or [Reinstall Driver]. If a message appears asking you to specify the location of the appropriate device driver, specify "USB Driver" in the CD supplied.

■ Please check the following if the movie clip doesn't play back.

※ If you installed an incorrect codec onto your PC, the movie clip may not play back on the PC.

1. Check whether the DirectX provided with the camera is installed.
→ If you didn't install the camera driver, please install the DirectX included in the application S/W CD-ROM. If not, the movie clip may not play back on the PC.

[Installing the DirectX]
1) Insert the CD provided with the camera.
2) Run the windows explorer and select the CD-ROM drive.
3) Select the DirectX8.1 folder and double click the Setup.exe file.
The codec will be installed.



Downloaded From camera-usermanual.com Samsung Manuals

- **If a PC (Windows 98) stops responding while the camera and PC are connected repeatedly**
  → If a PC (Windows 98) is turned on for a long time and connect the camera repeatedly, the PC may not recognise the camera. In this case, re-start the PC.

- **If a PC connected with the camera stops responding while the Windows is starting.**
  → In this case, disconnect the PC and the camera and the windows will start correctly. If the problem happens continuously, set the Legacy USB Support to disable and re-start the PC. The Legacy USB Support is in the BIOS setup menu. (The BIOS setup menu differs from the PC manufacturers and some BIOS menus don't have Legacy USB Support) If you can't change the menu by yourself, contact to the PC manufacturer or BIOS manufacturer.

- **If the movie clip can't be deleted, removable disk can't be extracted or an error message displays during the file transfer.**
  → If you install only the Digimax Viewer, the problems mentioned above occasionally happen.
  - Close the Digimax Viewer program by clicking the Digimax Viewer icon on the Taskbar.
  - Install all the application programs included in the software CD. (You must install the Movie clip codec)

Downloaded From camera-usermanual.com Samsung Manuals

SAMSUNG TECHWIN CO., LTD.
OPTICS & DIGITAL IMAGING DIVISION
145-3, SANGDAEWON 1-DONG, JUNGWONGU,
SUNGNAM-CITY, KYUNGKI-DO, KOREA
462-121
TEL : (82) 31-740-8086,8088, 8090, 8092, 8099
FAX : (82) 31-740-8398, 8111
www.samsungcamera.com

SAMSUNG OPTO-ELECTRONICS AMERICA, INC.
HEADQUARTERS
40 SEAVIEW DRIVE, SECAUCUS, NJ07094, U.S.A.
TEL : (1) 201-902-0347
FAX : (1) 201-902-9342

WESTERN REGIONAL OFFICE
18600 BROADWICK ST.,
RANCHO DOMINGUEZ, CA 90220, U.S.A.
TEL : (1) 310-900-5263/5264
FAX : (1) 310-537-1566
www.samsungcamerausa.com

SAMSUNG OPTO-ELECTRONICS UK LIMITED
SAMSUNG HOUSE
1000 HILLSWOOD DRIVE
HILLSWOOD BUSINESS PARK
CHERTSEY KT16 OPS U.K.
TEL : 00800 12263727
(free for calls from UK only)
SERVICE HOTLINE : 01932455320
www.samsungcamera.co.uk

SAMSUNG OPTO-ELECTRONICS GMBH
AM KRONBERGER HANG 6
D-65824 SCHWALBACH/TS., GERMANY
TEL : (49) 6196 66 53 03
FAX : (49) 6196 66 53 66
www.samsungcameras.de

SAMSUNG FRANCE S.A.S.
BP 51 TOUR MAINE MONTPARNASSE
33, AV .DU MAINE
75755, PARIS CEDEX 15, FRANCE
HOTLINE PHOTO NUMÉRIQUE :
00 800 22 26 37 27(Numéro Vert-Appel Gratuit)
TEL : (33) 1-4279-2200
FAX : (33) 1-4538-6858
www.samsungphoto.fr

SAMSUNG TECHWIN MOSCOW OFFICE
RUSSIA, 125167, MOSCOW LENNINGRADSKY,
PR-KT, 37-A, KORP14
TEL : (7) 095-258-9299/96/98
FAX : (7) 095-258-9297
http://www.samsungcamera.ru

TIANJIN SAMSUNG OPTO-ELECTRONICS CO.,LTD.
7 PINGCHANG ROAD NANKAI DIST., TIANJIN
P.R CHINA
POST CODE:300190
TEL : (86) 22-2761-8867
FAX : (86) 22-2761-8864
www.samsungcamera.com.cn

* Internet address - http : //www.samsungcamera.com/

CE The CE Mark is a Directive conformity mark of the European Community (EC)

6806-2560

Downloaded From camera-usermanual.com Samsung Manuals